

SAMSUNG
Galaxy Tab S2 nook[®]
User Guide



SAMSUNG
Galaxy
Tab S2 nook[®]

T A B L E T

User Manual

Please read this manual before operating your device
and keep it for future reference.

SAMSUNG

Legal Notices

Warning: This product contains chemicals known to the State of California to cause cancer and reproductive toxicity. For more information, please call 1-800-SAMSUNG (726-7864).

Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG mobile device, including but not limited to, accessories, parts, or software relating thereto (the “mobile device”), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Open Source Software

Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit: opensource.samsung.com.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT “AS IS”, AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Modification of Software

SAMSUNG IS NOT LIABLE FOR PERFORMANCE ISSUES OR INCOMPATIBILITIES CAUSED BY YOUR EDITING OF REGISTRY SETTINGS, OR YOUR MODIFICATION OF OPERATING SYSTEM SOFTWARE.

USING CUSTOM OPERATING SYSTEM SOFTWARE MAY CAUSE YOUR DEVICE AND APPLICATIONS TO WORK IMPROPERLY. YOUR CARRIER MAY NOT PERMIT USERS TO DOWNLOAD CERTAIN SOFTWARE, SUCH AS CUSTOM OS.

Samsung Knox

Samsung Knox™ is Samsung's security platform and is a mark for a Samsung device tested for security with enterprise use in mind. Additional licensing fee may be required. For more information about Knox, please refer to: samsung.com/us/knox. [030115]

Samsung Electronics America (SEA), Inc.

Address:

85 Challenger Road
Ridgefield Park,
New Jersey 07660

Phone:

1-800-SAMSUNG (726-7864)

Internet Address:

samsung.com

©2015 Samsung Electronics America, Inc. Samsung, Galaxy S, and Multi window are trademarks of Samsung Electronics Co., Ltd.

Do you have questions about your Samsung Mobile Device?

For 24 hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at: samsung.com/us/support.

The actual available capacity of the internal memory is less than the specified capacity because the operating system and default applications occupy part of the memory. The available capacity may change when you upgrade the device.

Nuance®, VSuite™, T9® Text Input, and the Nuance logo are trademarks or registered trademarks of Nuance Communications, Inc., or its affiliates in the United States and/or other countries.

The Bluetooth® word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG.

microSD™ and the microSD logo are Trademarks of the SD Card Association.

Google, the Google logo, Android, the Android logo, Google Play, Gmail, Google Mail, Google Maps, Google Music, Google Now, Chrome, Google Hangouts, Picasa, YouTube, and other marks are trademarks of Google Inc.

Wi-Fi is a registered trademark of the Wireless Fidelity Alliance, Inc.

Microsoft is a registered trademark of the Microsoft Corporation.

NOOK®, NOOK Books®, NOOK Catalogs™, NOOK Magazine®, NOOK Newspaper®, NOOK Newsstand®, NOOK Store®, NOOK Video™, ArticleView®, LendMe®, and the NOOK logos are trademarks of Nook Digital, LLC or its affiliates. Your use of NOOK is subject to the Terms of Service and Privacy Policy located in the Settings section of your device and here: NOOK.com/legal. Contains Reader® Mobile technology by Adobe Systems Incorporated. Adobe®, Reader®, and Reader® Mobile are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Your NOOK includes the Merriam-Webster's Collegiate® Dictionary, Eleventh Edition, with Geographic and Biographic Information. Merriam-Webster and Collegiate are trademarks of Merriam-Webster, Inc. and are used herein pursuant to license. Copyright © 2009-2011 Merriam-Webster, Inc. All rights reserved.

Ascender is a trademark of Ascender Corporation which is registered in the U.S. Patent and Trademark Office and certain other jurisdictions.

Georgia is a trademark of Microsoft Corporation which is registered in the U.S. Patent and Trademark Office and certain other jurisdictions.

Other company and product names mentioned herein may be trademarks of their respective owners.

Screen images used with permission of Nook Digital, LLC.

Legal Information

Important legal information can be accessed in writing on the mobile device or at samsung.com.

Read this information before using your mobile device.

Samsung Limited Warranty - This product is covered under the applicable Samsung Limited Warranty. Full written terms and detailed information about the warranty and obtaining service are available on the device at:

Settings > About device > Legal information > Samsung legal or at samsung.com.

The online version of the Health/Safety and Warranty guide for your device can be found at:

English

samsung.com/us/Legal/Tablet-HSGuide

Spanish

samsung.com/us/Legal/Tablet-HSGuide-SP

Location of Legal Information on the device:

- **Health and Safety Information**
Settings > About device > Legal information > Samsung legal > Health and Safety
- **Warranty**
Settings > About device > Legal information > Samsung legal > Warranty
- **EULA**
Settings > About device > Legal information > Samsung legal > End User License Agreement
- **NOOK Device Terms of Service**
NOOK Settings > Legal > Device Terms
- **NOOK Store Terms of Service**
NOOK Settings > Legal > Store Terms
- **NOOK Privacy Policy**
NOOK Settings > Legal > Privacy Policy

Table of Contents

Welcome	1	Google Applications	52
Getting Started	2	Microsoft Applications	54
Front View.....	3	Additional Applications.....	55
Back View.....	4	Calculator.....	56
Assemble Your Device	5	Calendar.....	57
Set Up Your Device	6	Camera.....	59
Setting Up Your NOOK	7	Clock.....	62
Set Up Accounts on Your Device	9	Contacts.....	64
Know Your Device	10	Email	67
Home Screen.....	11	Galaxy Apps	69
Status Bar	14	Gallery.....	70
Navigation, Motions, and Gestures	15	Internet.....	72
Notification Panel.....	17	Memo	74
Multi Window	19	Music Player.....	75
Enter Text	21	My Files.....	77
NOOK	23	Smart Manager	79
NOOK Features on the Home Screen.....	24	Video Player	80
NOOK Reader.....	27	Settings	82
NOOK Shop and the NOOK Store®	30	How to Use Settings	83
NOOK Apps.....	33	Wi-Fi.....	84
NOOK Library.....	34	Bluetooth	86
NOOK Video™	36	Flight Mode.....	88
NOOK Profiles	38	Data Usage.....	89
NOOK Settings.....	42	More Connection Settings.....	90
NOOK Search	44	Sounds and Notifications.....	91
Sideloaded Files.....	45	Display	93
Dictionaries	46	Motions and Gestures.....	95
NOOK Legal Information.....	47	Applications Settings.....	96
Applications	48	Users.....	99
Apps List	49	Wallpaper.....	100
NOOK Applications	51	Lock Screen and Security.....	101
		Privacy	105

Accessibility.....	107
Accounts.....	109
Backup and Reset.....	110
Language and Input Settings.....	111
Battery.....	114
Storage.....	115
Accessories.....	117
Date and Time.....	118
User Manual.....	119
About Device.....	120

Welcome

Welcome to the best of both worlds. The Samsung Galaxy Tab S2 NOOK® integrates our award-winning reading experience with leading edge technology, which means you can connect to the world when you need, and escape from it when you want. And with the fully integrated NOOK experience, reading, playing and purchasing content has never been easier. Enjoy your new device, and please come visit our NOOK centers at any Barnes & Noble store with your questions.

~ The NOOK Team

Contact Us

If you have questions about your NOOK that this guide doesn't answer, be sure to visit the NOOK online support center at:

[NOOK.com/support](https://www.nook.com/support)

The online support center offers additional information about your NOOK, including:

- A PDF version of this guide that you can download to your computer
- Tutorial videos
- Frequently Asked Questions
- Chat with a NOOK Expert

You can also contact Barnes & Noble Customer Support by sending email to:

nook@barnesandnoble.com

Stay in Touch

Follow us on Facebook and Twitter to receive daily reviews, exclusive offers, and free NOOK Books®.


<https://www.facebook.com/nook>

<https://www.twitter.com/nookbn>

Getting Started


Learn about your mobile device hardware, assembly procedures, and how to get started using your new device.

Front View



- **Back:** Tap to return to the previous screen, or to close a dialog box, menu, or keyboard.
- **Front camera:** Take pictures and record videos of yourself.
- **Home key and Finger scanner:** Press to return to the Home screen. Activate the Fingerprint security feature.
- **Light sensor:** Use the ambient light level to adjust the screen brightness and contrast.
- **Memory card slot:** Install an optional memory card (not included) for storage of files.
- **Microphone:** Records audio and detects voice commands.
- **Power key:** Press and hold to turn the device on or off. Press to lock or wake up the screen. Press and hold to turn the device off or restart it, or for quick access to Flight Mode.
- **Recent:** Tap to display recent apps or touch and hold for Home screen options.
- **Volume key:** Press to adjust the volume of your device's sounds.

Back View



- **Headset jack:** Connect an optional headset (not included).
- **Rear camera:** Take pictures and record videos.
- **Simple clicker:** These retractable circles securely attach optional covers (not included) to your device.
- **Speaker:** Plays music and other sounds.
- **USB charger/Accessory port:** Connect the Charger/USB cable (included), and other optional accessories (not included).

Assemble Your Device

This section helps you to assemble your device.

Install an Optional Memory Card

You can install an optional microSD or microSDHC memory card (not included) to expand available memory space.

Note: A memory card can be installed at any time; it is not necessary to install it prior to using the device.

For more information on installing a memory card, see [Install a Memory Card](#).

Charge the Battery

Your device is powered by a rechargeable, standard Li-Ion battery. A Wall/USB Charger (charging head and USB cable) is included with the device for charging the battery.

The battery comes partially charged. A fully discharged battery requires up to four hours of charge time. You can use the device while charging.

Caution: Use only Samsung-approved charging devices and batteries. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

1. Insert the USB cable into the port.



2. Connect the USB cable to the charging head, then plug the charging head into a standard AC power outlet.
3. When charging is complete, unplug the charging head from the power outlet and remove the USB cable from the device.


Caution: Failure to unplug the wall charger before you remove the battery can cause damage to the device.

When to Charge the Battery

When the battery is weak and only a few minutes of operation remain, the device sounds a warning tone at regular intervals.

In this condition, your device conserves its remaining battery power by dimming the screen.

When the battery level becomes too low, the device automatically turns off.

- For a quick check of your battery level, view the battery charge indicator located in the upper-right corner of your device's display. A solid color () indicates a full charge.

You can also choose to display a percentage value. Viewing a percentage value can provide a better idea of the remaining charge on the battery. For more information, see [Battery](#).

Set Up Your Device

Turn Your Device On or Off

Turn the Device On

- ▶ Press and hold the **Power** key until the device starts up.

Turn the Device Off

1. Press and hold the **Power** key until the device options menu displays.
2. Tap **Power off**.
3. On the window that appears, tap **POWER OFF**.

Secure Your Device

Use your device's screen lock features to secure your device.

Lock the Device

By default, the device locks automatically when the screen times out.

To lock the device:

- ▶ Press the **Power** key.

Unlock the Device

The default screen lock on your device is Swipe.

To unlock your device:

- ▶ Press the **Power** key or **Home** key, and then touch and drag your finger across the screen.

Set Up a Secure Screen Lock

The default Screen lock is Swipe, which offers no security. To choose a more secure screen lock, see [Set a Screen Lock](#)

Setting Up Your NOOK

The set-up process for your Samsung Galaxy S2 NOOK® guides you through setting up four types of accounts:

- A Google/Gmail account for accessing Google Play and the Google App Store.
- A Samsung account for buying and using Samsung apps.
- A NOOK account for accessing the NOOK Store® and NOOK content such as NOOK Books®, the NOOK Newsstand®, and NOOK apps.

Note: You have to connect to a Wi-Fi network to set up your NOOK.

When you first turn on your NOOK, it displays a Samsung Galaxy welcome screen.

1. Select your preferred language and tap the yellow arrow to continue.

Note: Accessibility options can be found by tapping on the Accessibility button.

2. Tap the name of the Wi-Fi network to which you want to connect. If the network displays a lock symbol, you are prompted to enter a password to connect to the network. If you do not know the password, ask the network administrator. Once you have entered the password in the password dialog box, tap **Connect**.
3. Once your NOOK connects to the network, tap **Next**.
4. Read the End User License Agreement (EULA) for Software. If you agree to the EULA, tap the checkbox by **I understand and agree to the terms and conditions above**. (If you do not agree to the EULA, you cannot use your NOOK.)
5. The EULA screen also offers you a chance to share diagnostic data with Samsung. Tap the checkbox to indicate your decision.
6. Tap **Next**.

Your NOOK prompts you to sign in to your Google account or to create a Google account if you do not have one. You need a Google account to access Google Play and other Google apps on your device.

7. If you want to make use of Google apps, either create a Google account or sign in to your existing Google account.
8. Setup billing information for payments to the Google Store or **Skip**.
9. Set the date, time, and time zone for your NOOK. Tap any of these items to call up a dialog box for making changes.
10. Tap **Next**.
11. Select what Google services you wish to participate in by tapping on each checkbox to select/deselect.
12. Tap **Next**.
13. Your NOOK prompts you to set up a Samsung account for accessing Samsung Galaxy apps. You can sign in, create a new account, or sign in with your Google ID. Tap the button with your choice. To skip setting up or signing in with a Samsung account, tap **Skip**.
14. Add fingerprint recognition if you wish to further secure your device or **Skip**.
15. Next your device displays a full-screen welcome page for NOOK. (Until you have set up a NOOK account, your NOOK displays this same welcome page whenever you launch any NOOK app such as the NOOK Library.)

Follow the steps below to set up your NOOK account.

Registering an Existing NOOK Account

If you already have a Barnes & Noble or NOOK account, tap **Sign In**.

1. On the Sign In screen, enter the email address and password for your account.
2. Tap **Sign In**.

Creating a New NOOK Account

If you do not already have a Barnes & Noble or NOOK account, tap **Create Account**.

1. On the screen for creating your account, enter:
 - Your first name
 - Your last name
 - The email address you want to use for your NOOK account
 - A password
 - A security question
2. Tap **Submit**. Your NOOK opens a dialog box with links to legal notices, including the NOOK Device Terms of Service, the NOOK Store Terms of Service, and the NOOK Privacy Policy. To read any of these notices, tap its link.
3. If you have read the legal notices and accept them, tap **Accept**.

Note: If you do not accept the legal terms, you cannot use your NOOK.

Note: Next you will set up a credit card for your account. You have the option of skipping this step, but you will not be able to make any purchases in the NOOK Shop until a credit card has been added to your account.

4. Add credit card information for your account. Enter:
 - The first name on the credit card account.
 - The last name on the credit card account.
5. Tap the pop-up menu to select the card type. Choose from:
 - Visa
 - MasterCard
 - Amex
 - Discover
 - DinersClub
 - JCB
6. Tap pop-up menus to select the expiration date for the credit card.
7. Tap **Next**.
8. Enter the billing address for the credit card. Enter:
 - Street address
 - City
 - State
 - ZIP Code
 - Country (either the United States or Canada)
9. Tap **Submit**.

Your NOOK enters this information and creates your account.

Set Up Accounts on Your Device

NOOK Account

Use your existing NOOK account or create a new one to make the best use of the NOOK features on your device. For more information, see [Setting Up Your NOOK](#).

For more information about the NOOK features, see [NOOK](#).



Google Account

Your new device uses your Google Account to fully utilize its Android features, including Gmail, Google Hangouts, and the Google Play store.

When you turn on your device for the first time, set up your existing Google Account or create a new Google Account.

– or –

To create a new Google Account or set up your Google Account on your device at any time, use Accounts settings. For more information, see [Accounts](#).

- ▶ From a Home screen, tap  **Apps** >  **Settings** > **Accounts** > **Add account** > **Google**.



Samsung Account

Create a Samsung account, for access to Samsung content and apps on your device.

When you turn on your device for the first time, set up your existing Samsung account or create a new Samsung account.

– or –

To create a new Samsung account or set up your Samsung account on your device at any time, use Accounts settings. For more information, see [Accounts](#).

- ▶ From a Home screen, tap  **Apps** >  **Settings** > **Accounts** > **Add account** > **Samsung account**.


Know Your Device

Learn some of the key features of your mobile device, including the screens and icons, as well as how to navigate the device and enter text using the keyboard.

Warning: Please note that a touch screen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touch screen may damage the tempered glass surface and void the warranty.

Home Screen

The Home screen is the starting point for using your device.



- **App shortcuts:** Shortcuts to your favorite applications.
- **Apps list:** Allows quick access to all of your applications.
- **Apps folder:** For your convenience, there are several applications that are grouped into a folder on the main Home screen.
- **Home screen indicator:** Indicates which Home screen is presently displayed.
- **NOOK Library widget:** Displays books, periodicals, or apps from your Library.
- **Notification icons:** Displays new messages and emails, notifications, available software updates, and so on.
- **Status bar:** Displays device status icons (right) and notification icons (left).
- **Status icons:** Displays information about the device, such as the network signal strength, battery level, the time, and so on.
- **Widget:** Self-contained application (not a shortcut) that runs on a Home screen.

Customize your Home screen by adding application shortcuts, widgets, folders, and using wallpapers.

Manage Home Screens

Your device comes with multiple Home screens to hold apps and widgets. You can rearrange the Home screens in a different order.

1. From a Home screen, pinch the screen.
2. Use these options to manage screens:
 - **Add a screen:** Swipe to the end of the screens, and then tap **+** **Add**.
 - **Remove a screen:** Touch and hold a screen, and then drag it to **Remove**.
 - **Set a screen as the main Home screen:** Tap **Main Home screen** at the top of a screen. This screen displays when you press the Home key.
 - **Change the order of screens:** Touch and hold on a screen, and then drag to a new position.
 - **Premium Services:** Swipe to the left of the screens to find the Premium Services set up screen. To activate this feature, tap the checkbox at the top center of the screen. Tap **Contents settings** and then tap **NOOK** or **Flipboard Briefing**.

Change the Wallpaper

Change the look of the Home and Lock screens with wallpaper. You can display a favorite picture or choose from preloaded wallpapers.

1. From a Home screen, pinch the screen.
2. Tap **Wallpapers**, and then choose **HOME SCREEN**, **LOCK SCREEN**, or **HOME AND LOCK SCREENS**.
3. Tap a wallpaper to see a sample, and then tap **SET AS WALLPAPER**.

For more information, see [Wallpaper](#) in Settings.

Widgets

Widgets are self-contained apps that run on a Home screen. There are all kinds of widgets, including links to a specific contact, Internet bookmarks, Gmail and email accounts, and many others.

Add a Widget to a Home Screen

1. From a Home screen, pinch the screen.
2. Tap **Widgets**.
3. Touch and hold a widget, drag it to a Home screen, and release it.

Remove a Widget


1. From a Home screen, touch and hold a widget to release it.
2. Drag the widget to **Remove** and release it.

Note: Removing a widget does not delete the widget, it just removes the widget from the Home screen.


App Shortcuts

You can use app shortcuts to launch an app from any Home screen.

Add a Shortcut to a Home Screen

1. From a Home screen, tap  **Apps**.
2. Touch and hold an app shortcut, drag it to a Home screen, and release it.

Remove a Shortcut

1. Touch and hold a shortcut to release it.
2. Drag the app shortcut to  **Remove** and release it.


Note: Removing a shortcut does not delete the app, it just removes the shortcut from the Home screen.

Folders


Place folders on a Home screen to organize items.

Create a Folder

You can create app folders on a Home screen.

1. Touch and hold an app shortcut and drag it on top of another app shortcut until a highlighted box displays.
2. Release the app shortcut to create the folder.
 - Tap **Enter folder name** to enter a name for the folder.
 - Tap  **Palette** to change the color.
3. Tap anywhere outside of the folder to close it.
 - To add more apps, touch and hold an app shortcut and drag it to the folder.

Remove a Folder from a Home Screen

1. Touch and hold the folder until it detaches.
2. Drag the folder to  **Remove** and release it.

Status Bar

The Status bar at the top of the Home screen provides device information (such as network status, battery charge, and time) on the right side and notification alerts on the left.

Status Icons



Battery is fully charged.



Battery is low.



Battery is charging.



Mute mode is enabled.



Wi-Fi is active.

Notification Icons



New email has arrived.



New Gmail has arrived.



Download of a file or app is in progress.



File is being uploaded or sent.



Location service (GPS) is active.



App updates are available from the Google Play store.



App installation or updates are complete.



Keyboard is in use.

Navigation, Motions, and Gestures

Learn the basics for how to navigate through your device, and basics for how to customize screens by editing, sharing, and deleting items.

Touchscreen Navigation

Tap

Lightly tap items to select or launch them.

- Tap the onscreen keyboard to enter characters or text.
- Tap an item to select it.
- Tap an app icon to launch the application.

Touch and Hold

Activate onscreen items by a touch and hold gesture.

- Touch and hold a widget on a Home screen to move it.
- Touch and hold a field to display a pop-up menu of options.

Swipe or Slide

To swipe, lightly drag your finger vertically or horizontally across the screen.

- Unlock the screen.
- Scroll through the Home screens or menu options.

Drag

To drag, touch and hold on an item, and then move it to a new location.

- Add a shortcut to a Home screen.
- Move a widget on a Home screen.

Pinch and Spread

Pinch the screen using your thumb and forefinger or spread by moving your fingers apart.

- Zoom in or out while viewing a picture or a Web page.
- Zoom in or out while taking a picture.

Motions and Gestures

Control your device by making specific gestures with your hand above the device's screen. For more information, see [Motions and Gestures](#) in Settings.

To access the Motions and Gestures settings:

- ▶ From a Home screen, tap  **Apps** >  **Settings** > **Motions and gestures**.


Common Options

The device uses basic command options to perform common actions.

- **MORE:** Tap to view more menu options for a screen. This usually allows you to select items to delete or share.
- **DELETE:** Tap to select items to delete. Often you can tap a checkbox at the top of the screen to select all.
- **SHARE:** Tap to select items to share, and a sharing method. Often you can tap a checkbox at the top of the screen to select all.
- **EDIT:** Tap to customize the screen.

Notification Panel

Notification icons on the Status bar display calendar events, device status, and more. For details, open the Notification panel.



- **Clear notifications:** Tap to clear all notifications.
- **Edit Quick settings:** Tap to change which Quick settings buttons are visible.
- **Manage users:** Tap to manage user accounts.
- **Notification card:** Tap to see details about a notification. Swipe a notification card to the right to dismiss it.
- **Quick settings:** Tap to quickly enable or disable a feature. Swipe to the left to see more settings.
- **Screen brightness:** Drag the slider to adjust screen brightness. Tap **Auto** to have the tablet set the screen brightness using its light sensor.
- **Settings:** Tap to open the Settings screen.

View the Notification Panel

1. Swipe down on the Status bar to display the Notification panel.
2. Scroll down the list to see notification details.
 - Tap an item to open it.
 - To clear a single notification, drag the notification left or right. Tap **Clear** to clear all notifications.
3. To close the Notification panel, swipe upward from the bottom of the screen or tap **Back**.

Quick Settings

In addition to notifications, the Notification panel also provides quick access to device functions such as Wi-Fi, allowing you to quickly turn them on or off.

To view additional Quick settings:


- ▶ Swipe left or right across the visible icons.

To customize Quick settings:

- ▶ On the Notification panel, tap **EDIT**.

S Finder

Search for a wide variety of content with a keyword.

1. Swipe down on the Status bar to display the Notification panel.
2. Tap **S Finder**.
3. Enter a keyword in the **Search device** field, or tap  **Google voice typing** and say a keyword.

You can narrow the search by tapping Category, Time, Location, or Tag and using preset search options. Items that match your search display below.

4. Tap items to open them.

Use Search Location

You can search for content in specific locations.

- ▶ Tap **MORE > Select search locations** and select categories.

Quick Connect

Automatically search for nearby devices and quickly connect to them.

- If the device you want to connect does not support the Quick connect feature, activate its Wi-Fi Direct feature before launching Quick Connect on your device.
- Connection methods may vary depending on the type of connected devices or the content being shared.

Connect to a Device

1. Swipe down on the Status bar to display the Notification panel.
2. Tap **Quick Connect**.
 - If you are using this feature for the first time, select a visibility option and tap **TURN ON QUICK CONNECT**.

When the Notification panel opens, Wi-Fi is activated automatically and the tablet searches for nearby devices.

3. Tap a device and follow the instructions.
 - To change your device's visibility setting, tap **SETTINGS > Device visibility**, and then select an option.
 - If the desired device does not appear in the list, tap **REFRESH**.


Share Content

Share content with a connected device.

1. Swipe down on the Status bar to display the Notification panel.
2. Tap a device from the list of detected devices.
3. Tap **Share content** and select a media category.
4. Follow the instructions to send content to the connected device.

Multi Window


Multitask by using multiple applications at the same time.



Activate Multi Window

Apps that support Multi window display together on a split screen. You can switch between the apps, adjust the size of their display on the screen, and copy information from one app to the other.



Note: Multi window is not available for all apps.

1. From any screen, touch and hold  **Recent**.
2. If you are currently using an app that supports Multi window, tap an app to add in split screen, or tap two new apps to open in split view.

- or -


Tap two apps that support Multi window to open them in split screen view.

You can also launch recently used apps directly into Multi window view:

1. Tap  **Recent**.
2. Recently used apps that support Multi window have a  **Multi window** icon in the title bar. Tap the Multi window icon in the title bar to launch the application in Multi window view.
3. Other recently used apps that support Multi window appear below the launched app. Tap the app icon to add it to the split screen view.

Note: Only applications that support Multi window have the Multi window icon.

Window Controls

Select an application window and tap  **Control** in the middle of the window to display the window controls.

Control Buttons



Switch windows: Switch the positions of two Multi Window applications.



Drag and drop content: Move items between the application windows. Drag an item to share from one window to another. Some applications may not support this feature.



Minimize window: Minimize the selected app window. This turns the app into a circular, movable icon that can be opened by tapping on it.



Maximize window: Open the selected window in full screen view.




Close app: Close the selected application.

Enter Text

Text can be entered using an onscreen keyboard or by speaking.


Use the Samsung Keyboard


Enter text using a QWERTY keyboard.




Note: The available Options keys depend on the application in use. Not all options are available for all apps.


Special Keys


 Tap to insert numbers and symbols.


 Tap to insert letters.


Touch and hold the **Options** key to:


 Use Google voice typing.

 Use your handwriting to enter text.

 Access the clipboard.

 Insert emojis.

 Change the layout of the keyboard.



 Access keyboard settings.

Predictive Text

Predictive text suggests words matching your text entries, and, optionally, completes common words automatically. Predictive text can learn your personal writing style from your contacts, messages, email, and social networking sites—improving its accuracy of predicting your text entries.


Configure the Samsung Keyboard

To customize the Samsung Keyboard:


1. From a Home screen, tap  **Apps** >  **Settings** > **Language and input**.
2. Tap **Samsung keyboard** for options.

Use Google Voice Typing

Instead of typing, enter text by speaking.





To enable Google voice typing:

1. On the Samsung Keyboard, tap  **Google Voice Typing**.
 - You may need to touch and hold **Options** (left of the Space key) to find it.
2. Speak your text.

Note: Tap [Languages](#) to download additional languages for use with Google voice typing.

Configure Google Voice Typing

To customize Google voice typing:

1. From a Home screen, tap  **Apps** >  **Settings** > **Language and input**.
2. Tap **Google voice typing** for options.


NOOK

The Samsung Galaxy Tab S2 NOOK® integrates NOOK's award-winning reading experience and Barnes & Noble's enormous selection of content with Samsung's leading edge technology, allowing you to connect to the world when you need and escape from it when you want.

And with the fully integrated NOOK® experience, browsing, purchasing, and enjoying your content has never been easier. Enjoy your new device, and please visit your neighborhood Barnes & Noble store where our booksellers are always ready to help.

NOOK Features on the Home Screen

The Home screen features widgets and apps shortcuts that provide quick and easy access to your NOOK Library and to new NOOK Content.




NOOK Library Widget

This widget displays books, periodicals, or apps from your Library. A scrollable carousel presents the items you have most recently purchased or accessed.

- To open a book or periodical, tap its cover.
- To see a broader selection of content, swipe left or right to scroll through a carousel of recently purchased or accessed items.

Current Read

The  **Current Read** shortcut in the lower left-hand corner of the main Home screen provides a shortcut to the book or periodical you have been reading most recently.

App Shortcuts

The Home screen features shortcuts to these apps:



NOOK Shop

Opens the NOOK Store where you can shop for books, periodicals, and apps.



NOOK Search

Lets you search the NOOK Store and your Library for keywords.



NOOK Home

Presents new recommendations and promotions from the NOOK Store.

NOOK Home


The NOOK Home app presents recommendations and special offers from the NOOK Store.





To access NOOK Home:

- ▶ From a Home screen, tap  **NOOK Home**.


By default, the NOOK Home app appears in the row of app shortcuts on the Home screen.

NOOK Navigation Menu

A  **Menu** in the upper left corner of several NOOK apps makes it easy to move from one NOOK feature to another. The NOOK Navigation Menu is available in these apps:

-  NOOK Home.
-  NOOK Shop.
-  NOOK Library.
-  NOOK Settings.

The NOOK Navigation Menu is also available in the current NOOK Book you are reading, as well as in NOOK Magazines and NOOK Newspapers.

Look for  **Menu** (three horizontal lines) in the upper left corner of the screen. In a NOOK Book or periodical, open the Reading Tools to see the menu's icon.

To open the menu, either touch its icon or swipe to the right from the left edge of the screen.

Once opened, the menu displays these choices:

- Current Read
- Home
- Shop
- Library
- Messages
- Settings

Tap the choice to go to the NOOK feature or content you want. For example, tap **Current Read** to return to the book or periodical you were most recently reading or tap **Shop** to visit the NOOK Store.

NOOK Shortcut to Book

You can add a Home screen shortcut to a NOOK Book or any other NOOK content. Tapping the shortcut automatically opens the NOOK content linked to the shortcut.

To add a shortcut to a NOOK Book, a NOOK Magazine, or other NOOK content:

1. From a Home screen, pinch the screen, and then tap **Widgets**.
2. Swipe through the widgets, and tap **NOOK widgets**.
3. Touch and hold the widget called **NOOK Shortcut to Book** to place it on a Home screen.

You can select a location on any Home screen panel. Once you have placed the widget, a scrollable panel opens, displaying the contents of your Library.

4. Scroll through your Library and select the NOOK item for which you want to create a shortcut. If you do not see the item you want, tap **more** at the bottom of the panel to open the full contents of your Library. If you selected a NOOK Magazine, you are prompted to pick either the current issue or a specific back issue.
5. Once you have selected the content, a flexible bounding box appears around the shortcut. To resize the shortcut, drag one of the sides of the bounding box.
6. Tap outside the shortcut to finish placing and resizing it.

You can create as many shortcuts as you can fit on your Home screen panels.

NOOK Reader

Open a Book or Periodical

To open a book or periodical in the Library or the Library widget:

- ▶ Tap the cover of the item.

Turn Pages


To turn to the next page:

- ▶ Tap the right side of the screen.
 - or -
 - Swipe from the right side of the screen.

To turn back to the previous page:

- ▶ Tap the left side of the screen.
 - or -
 - Swipe from the left side of the screen.


Display the Table of Contents

1. Tap the center of the page.
2. Tap  **Table of Contents** to open the Contents window.
3. Tap a chapter or section to open it.

Place a Bookmark

- ▶ Tap the **upper right hand corner** of the screen to add a  Bookmark ribbon.



View a List of Bookmarks

1. Tap the center of the page.
2. Tap  **Table of Contents** to open the Contents window.
3. Tap the **BOOKMARKS**.
4. Tap the page in the list of bookmarked pages to open that page.


Change Type Size, Font, Margins, and Other Page Elements

1. Tap the center of the page.
2. Tap **Aa Text Settings** to open the Text Options window.
3. Select the type size, font, margins, line spacing, and color theme you want. If the publisher has recommended a page design, you can switch to it by moving the slider for **Publisher Defaults** to on.


Search a Book

1. Tap the center of the page.
2. Tap  **More options** to open the options menu.
3. Tap **Find in Book**.
4. Type the word or phrase you want to find.
5. Tap  **Search** on the keyboard.

View the Details Page

1. Tap the center of the page.
2. Tap  **More options** to open the options menu.
3. Tap **View Details**.

Configure Reader Settings

1. Tap the center of the page.
2. Tap  **More options** to open the options menu.
3. Tap **Settings**.
4. On the Settings screen, tap an option to configure the Reader.

Lend a Book to a Contact



Barnes & Noble's popular LendMe® feature allows customers to lend eligible NOOK Books® to a friend, at no cost, for up to 14 days. All LendMe functionality is consolidated online at MyNOOK.com. Visit MyNOOK.com to lend and borrow eligible NOOK Books, as well as to accept LendMe offers from friends. You read and enjoy LendMe-eligible NOOK Books on your NOOK devices and through the Free NOOK Reading Apps registered to your NOOK account.

For more information about lending and borrowing NOOK Books, visit MyNOOK.com.

Display the Status Bar in Books

By default, your NOOK does not display the black Status Bar with the battery and Wi-Fi icons, the clock, and other notifications when you are reading a book.



To display the Status Bar in books:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader**.
3. Tap **Always Show Status Bar**, making sure that the checkbox is selected.

Change the Page Turn Effect

Your NOOK offers a choice of three animated effects when you turn a page in a NOOK Book or other EPUB-formatted ebook or magazine. The page can curl as though you were turning a paper page, one page can slide smoothly to the other, or there can be no special effect at all as the one page simply flashes to the next.

To select the Page Turn Effect you want for Books:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader**.
3. Tap **Books**, and then select the Page Turn Effect you want: **None**, **Slide**, or **Curl**.

To change this setting for Magazines, tap **Magazines & Newspapers**, and select the turn effect you want: **Slide** or **Curl**.

Read Newspapers and Magazines

Newspapers and magazines use many of the same reading features as books.

Page View and ArticleView®

Some magazines and newspapers present two ways of viewing content.

Page View presents an onscreen replica of the printed page.


ArticleView displays the text of an article in an easy-to-read, scrollable format. You can scroll up and down to read the article. Swipe right and left to move from one article to another.

In publications that support these features, a button at the bottom of the screen lets you toggle between Page View and ArticleView.

In publications that do not support Page View and ArticleView, use the navigation tools and gestures you use in books to move from page to page and section to section.

Additional Features in ArticleView



In ArticleView, tap the center of the page to open Reading Tools at the top of the Screen.

- Tap **Aa Text Settings** to open controls for formatting the page.
- Tap the grid icon (9 small squares) to display all pages as thumbnail images in a scrollable grid. To jump to a page in the grid, tap it.
- Tap  **Table of Contents** to see a scrollable table of contents for the publication.

Catalogs

Your NOOK supports catalogs with interactive hotspots. Tapping one of these hotspots opens a browser that takes you to a Web page about an item or topic in the catalog. By default, hotspots are turned on.



To turn hotspots for catalogs on or off:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader** > **Enable HotSpots** to turn hotspots on or off.

Comics

Your NOOK supports comics. Zoom View Letterboxing is a feature that lets you move from frame to frame, even if the frames are different sizes.

To turn on Zoom View Lettering boxing:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader** > **Zoom View Letterboxing** to enable.

Open DRM-protected Files

DRM stands for Digital Rights Management. DRM software protects books from being copied, sold, or distributed in an unauthorized manner.


Your NOOK and the Barnes & Noble website automatically make sure that when you buy and download a NOOK Book, the NOOK Book recognizes you as its legitimate owner and presents its contents for you to read on your NOOK.

NOOK Shop and the NOOK Store®


To reach the NOOK Store, launch the NOOK Shop app or tap the shopping bag icon at the top of the screen in any other NOOK app.

By default, the NOOK Shop app appears in the row of app shortcuts on the Home screen.


Buy a Book in the Shop

1. From a Home screen, tap  **NOOK Shop**.
2. Tap **BOOKS**, and tap a book's cover to display its Details page.
3. Tap the **Buy** button.
4. Tap **Confirm**.

Buy a Single Issue of a Magazine or Newspaper


1. From a Home screen, tap  **NOOK Shop**.
2. Tap **MAGAZINES**, and tap the cover of the magazine or newspaper.
3. Tap **Buy Issue**.
4. Tap **Confirm**.

Subscribe to a Magazine or Newspaper

1. From a Home screen, tap  **NOOK Shop**.
2. Tap **MAGAZINES**, and tap the cover of the magazine or newspaper.
3. Tap **Try for Free**.
4. If the periodical offers a choice of annual or monthly subscriptions, tap the type of subscription you want.
5. Tap **Start My Free Trial**.


Buy or Rent a Movie

Renting give you 30 days to start watching. Once you begin watching, you have 24 hours to finish.



1. From a Home screen, tap  **NOOK Shop**.
2. Tap **MOVIES & TV**, and tap the cover of the movie.
3. Tap **Buy** or **Rent**. If the movie is available in SD and HD formats, select the format you want. A dialog box opens.
4. Confirm that you want to complete the purchase or rental.

Buy a TV Show



You can buy either an entire season of a TV show or individual episodes.

1. From a Home screen, tap  **NOOK Shop**.
2. Tap **MOVIES & TV**, and tap the TV show you want to buy.
3. To see a list of individual episodes, scroll down the Details page.

View Your Wishlist



1. From a Home screen, tap  **NOOK Shop**.
2. Tap  **More options > Wishlist**.

Add a Shop Item to Your Wishlist

1. From a Home screen, tap  **NOOK Shop**.
2. Tap the Details page for the item you want to add to your Wishlist.
3. Tap  **More options > Add to Wishlist**.

Manage Credit Cards



You can also manage your credit card on NOOK.com.

1. From a Home screen, tap  **NOOK Shop**.
2. Tap  **More options > Shop Settings**.
3. Tap **Credit Cards**.
4. Tap **Change**.
5. Enter the first name and last name of the account holder.
6. Select the card type. Choose from:
 - Visa
 - MasterCard
 - Amex
 - Discover
 - DinersClub
 - JCB
7. Select the expiration month and year.
8. Tap **Next**.
9. Enter the billing address.
10. Tap **Submit**.

Manage Gift Cards

You can apply a gift card to purchases on your NOOK. A card number and a 4-digit PIN appear on the back of gift cards.



Once the gift card is used up, new purchases will be charged to the default credit card associated with the primary profile.

1. From a Home screen, tap  **NOOK Shop**.
2. Tap  **More options > Shop Settings**.
3. Tap **Gift Cards**.
4. Tap **Add Gift Card**.
5. Tap the **Card or Certificate Number** field and enter the number for the gift card.
6. Tap the **PIN** field and enter the 4-digit PIN for the card.
7. Tap **Submit**.



Redeem Access Codes

An access code is a 13-digit code that is available on a receipt or a card you received in a store or in the body of an email confirmation message.



To redeem an access code for a NOOK Book:

1. From a Home screen, tap  **NOOK Shop**.
2. Tap  **More options > Shop Settings**.
3. Tap **Redeem Access Code**.
4. Tap the Enter Access Code field and type the 13-digit number.
5. Tap **Add Now**.

Clear Recent Shop Searches

1. From a Home screen, tap  **NOOK Shop**.
2. Tap  **More options** > **Shop Settings**.
3. Tap **Clear Search History**.
4. Tap **OK**.

Clear Recent Browsing History



1. From a Home screen, tap  **NOOK Shop**.
2. Tap  **More options** > **Shop Settings**.
3. Tap **Clear Browsing History**.
4. Tap **OK**.

NOOK Apps

The NOOK Apps application displays the NOOK apps you have purchased that are supported on the Samsung Galaxy Tab S2 NOOK.

If you have not purchased any NOOK apps yet, the NOOK Apps application displays a shortcut button that takes you directly to the Apps section of the NOOK Store.



To access NOOK Apps:

- ▶ From a Home screen, tap  **Apps** >  **NOOK Apps**.

NOOK Library

In the NOOK Library app, you can see all your books, periodicals, TV shows and movies, and catalogs. You can also see all the NOOK apps you have purchased that are supported on the Samsung Galaxy Tab S2 NOOK.




To open any item in your Library,

- ▶ From a Home screen, tap  **Apps** >  **NOOK Library**, and tap the cover of item.

Organize Library Items in Shelves




You can create shelves to organize Library content as you wish. Items added to shelves remain visible in the main areas of the Library.

Create a Shelf




1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Tap  **More options** > **New Shelf**.
3. Type a name for the shelf.
4. Tap **Save**.
5. Select the items you want to include in the shelf. Tap the names of content categories like Books to see a list of all the items in that category. Tap the checkbox next to an item to add it to the Shelf.
6. Tap **Save**.

Manage the Content in a Shelf

To add or remove content in a shelf that you previously created:




1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Swipe down and tap My Shelves.
3. Tap a Shelf to open it.
4. Tap  **More options** > **Manage Content in Shelf**.
5. Use checkboxes to select or deselect items for the shelf.
6. Tap **Save**.

Rename a Shelf

1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Swipe down and tap My Shelves.
3. Tap a Shelf to open it.
4. Tap  **More options** > **Rename Shelf**.
5. Type a new name for the shelf.
6. Tap **Rename**.




Remove a Shelf

Removing a shelf does not delete any of the items on the shelf. They remain available in the Library.




1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Swipe down and tap **My Shelves**.
3. Tap a Shelf to open it.
4. Tap  **More options** > **Remove Shelf**.
5. Tap **Remove**.

View Content in Your NOOK Archive

You can archive books and periodicals in the NOOK Cloud.



1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Tap  **More options** > **View Archive**.
3. To download an item, tap its cover.
4. To return to the Library, tap the left arrow in the top left-hand corner of the screen.

Refresh the Content in Your Library

1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Tap  **More options** > **Refresh**.

Remove an Item from Your Device

You can remove an item such as a book from your device. An image of the item remains in your Library, so that you can download it again later if you like.

1. From a Home screen, tap  **Apps** >  **NOOK Library**.
2. Tap and hold on the cover of the item.
3. Tap **Remove from device**.

NOOK Video™ is a streaming and download service that allows you to rent movies and purchase movies and TV shows for viewing on your NOOK. NOOK Video offers a wide variety of popular movies and TV shows.

NOOK Video supports both streaming and downloading content. When you purchase or rent a movie, you need to select how you will access it: streaming or downloading. Unlike books and periodicals, videos do not download automatically when purchased.

Streaming means that the content is delivered over an active Wi-Fi connection. You must be connected to a Wi-Fi Internet connection to watch streamed content. Streaming videos does not require any storage on your NOOK.



Note: When streaming content, it's best to have to a strong Wi-Fi connection.

Download Videos

Downloading means that you transfer the NOOK Video content over a Wi-Fi connection to your NOOK just as you download other content like books and magazines. Once you have downloaded a NOOK Video, you can watch it any time regardless of whether or not your NOOK is connected to Wi-Fi (though rented content must be watched within the rental period, as described below). Unlike streamed videos, downloaded videos do consume storage on your NOOK.

If you plan to download many videos, you should consider purchasing a microSD card to give your NOOK extra storage.

To configure your NOOK to download video content to an SD card, rather than to internal storage:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Video**.
3. Tap **Video Download Location** to enable.

Note: Downloading videos may take some time. The speed of the download will depend on the length of the video and the bandwidth of your Wi-Fi network. If you are planning to download a movie to watch it offline (for example, in a location without a Wi-Fi network, such as in a car or on a plane), we recommend that you connect your NOOK to a power source and begin downloading the movie as soon as you have purchased or rented it.

Rent Movies

You can rent movies on your NOOK.

Once you rent an item, you have 30 days to begin watching it.

Once you start watching it, you have 24 hours to finish watching it before the rental expires. You can watch the item as many times as you like within that 24-hour period.

You can stream an item to begin watching it right away, or you can download an item to begin watching it within the 30-day rental period.

Note: You may download a rented movie to only one device during the rental period, so be sure to download only on the device on which you intend to watch the movie. In contrast, you may stream movies on all authorized NOOK devices during the rental period. You may authorize up to five devices through your NOOK account.

Closed Captioning

Your NOOK supports closed captioning on select NOOK Video titles.

Note that not all titles include Closed Captioning data.



UltraViolet™

UltraViolet is an all-new way to collect, access, and enjoy your movies and TV shows in the cloud.

Purchase a Blu-ray, DVD, or digital video with the UltraViolet logo, and you can stream or download your movie or TV show to your UltraViolet-compatible devices, including your NOOK.

Visit www.myuv.com to set-up an UltraViolet account, and link your UltraViolet account to your NOOK account from your NOOK.

To link your accounts:



1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Video > UltraViolet™ Account**, and follow the instructions.

To add a DVD or Blu-ray to your digital collection, simply follow the instructions inside the packaging. If your UltraViolet account is linked on your NOOK, digital purchases will be automatically added to your UltraViolet collection, free with purchase.

Instantly stream or download UltraViolet movies and TV shows from your NOOK Library on your NOOK.

Manage NOOK Video on Your Devices

NOOK Video allows you to access NOOK Video content on up to five devices at a time. To select which of your NOOK devices has access to NOOK Video:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Video > Manage NOOK Video**. The screen lists the NOOK devices associated with your account and authorized to access NOOK.
3. To remove a device from the list, tap its name. A dialog box opens, asking you to confirm that you want to de-authorize the device.
4. Tap **Confirm**.

NOOK Profiles

A NOOK Profile™ tailors content and shopping experiences on your NOOK for an individual user.

Your NOOK supports up to six NOOK profiles, enabling different people to use your NOOK in different ways.



Types of Profiles

Your Samsung Galaxy Tab S2 NOOK supports three types of NOOK Profiles:

- **Primary Profile:** This is the profile created by default when you register your NOOK. This profile can view all the content on the device and can also create and edit profiles for other users and manage those profiles' access to content. All purchases made on the NOOK are processed using the payment method associated with this profile.
- **Adult Profile:** An adult profile can purchase any type of content. An adult profile can also control which content is visible to itself and which content is visible to any child profile. It can also set parental controls for child profiles. It cannot control which content is visible to the primary profile.
- **Child Profile:** By default, a child profile can only view and purchase content authorized by the primary profile or through parental controls configured by an adult profile. A child profile does not have the ability to create or edit other profiles. It cannot override parental controls.


Set up a New or Existing Adult Profile

To set up an adult profile:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Profile**
3. Tap the (+) sign in the upper right corner.
4. Type a **First Name** for the new profile and select if you want existing NOOK shop content available on the new profile.
5. Tap **Next** to complete.

Switch Between Profiles

To switch between profiles:

1. Tap the  **BCC?** **BUJ** **Ujcb** **A Ybi** **Á** **ã** **Á** **PUUSA** **@** **] ÁNOOK** **S** **ã** **æ** **Ä** **ÁNOOK** **P** **{** **^** **É**
2. Tap the Name of the current Profile shown and a list of additional Profiles for this device will be shown.
3. Tap the Profile Name you wish to switch to.

Create a Child Profile

Simple-to-use parental controls help create a “kid-safe” experience on your NOOK. Using parental controls, you can limit the types of content that child profiles can view and purchase. You set up parental controls when you create a child profile. You can adjust them later if you like by editing the child profile.



Using parental controls, you can control whether or not a specific child profile can:

- Browse the NOOK Shop
- Purchase from NOOK Shop only when using your NOOK account password
- Shop only for kids’ content in the NOOK Shop
- Access Reads for kids
- Access Video for kids
- Access Apps for kids
- Access Games for kids

In addition, you can select the TV and movie ratings the child profile is allowed to access. Choices include:


- G
- PG
- PG 13
- TV Y
- TV Y7
- TV G
- TV 14

To create a child profile:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Profile**.
3. Tap the (+) sign in the upper right corner.
4. Type a **First Name** for the child profile, tap the checkbox next to **Child Profile**, enter the child's age, and accept the Terms & Conditions.
5. Tap **Next**.
6. Select the permissions that you want to enable.
7. Tap **Next** to complete.

Switch Between Profiles



To switch between profiles:

1. Tap the  **BCC?** **BUJ** **Ujcb** **A Ybi** **Á** **ã** **Á** **PUUSA** **@** **]** **Á** **NOOK** **Sã** **æ** **Á** **Á** **NOOK** **P** **{** **^** **É**
2. Tap the Name of the current Profile shown and a list of additional Profiles for this device will be shown.
3. Tap the Profile Name you wish to switch to.

Delete a NOOK Profile

Note: Deleting a user's NOOK profile does NOT remove the primary user account from the device.

To delete a NOOK profile:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Profile**.
3. Tap the trash icon next to the Profile you wish to delete and then tap **Delete** to confirm the removal.

Manage Content for a Profile

Share Content

The same content can be shared by multiple profiles. Each profile may need to download the content independently to access it.

For example, if the Primary Profile owns a particular NOOK Book and grants another profile access to it, the book may appear in the other profile's Library with a download icon, indicating that the book is available for download. To read the book, the other profile simply has to tap its cover to download it to the profile's storage area on your NOOK.

Annotations, such as notes and highlights, are specific to a profile. If one profile makes notes and highlights in a book, they will not be visible to other profiles reading the same book.

Similarly, if two profiles own the same book, their reading positions in the book are tracked independently. If one profile reads to page 17 and the other profile reads to page 25, each profile will be taken to his or her most recently read page when the book is reopened. The first profile will be returned to page 17; the second profile to page 25.

Assign Content to Other Profiles

The primary profile can assign content to adult profiles and child profiles. An adult profile can assign content to child profiles.



Manage Access to a Single Item

To manage access to a particular book, magazine, or other Library item:

1. From the **NOOK Library**, tap and hold on the cover of the item.
2. Tap **Assign to Profiles**.
3. Tap the checkboxes to select which profiles should have access to the item.
4. Tap **Save**.



Manage Access to Many Items or Content Categories

To manage access to many items or item categories,:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Profile**.
3. Tap the pencil icon next to the Profile you want to edit and then select the content that you want to make available for this profile.
4. Tap **Save**.

Manage Parental Controls for a Child Profile

To manage parental controls for a child profile:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Profile**.
3. Tap the **Lock Icon** next to the child profile you want to manage.
4. Use checkboxes to select the apps and content the child profile should have access to.
5. Tap **Done**.

Note: NOOK parental controls do not control non-NOOK apps, such as apps in the [Google Play store](#).

Using parental controls, you can control whether or not a specific child profile can:

- Browse the NOOK Shop
- Purchase from NOOK Shop only when using your NOOK account password
- Shop only for kids' content in the NOOK Shop
- Access Reads for kids
- Access Video for kids
- Access Apps for kids
- Access Games for kids

In addition, you can select the TV and movie ratings the child profile is allowed to access. Choices include:



- G
- PG
- PG 13
- TV Y
- TV Y7
- TV G
- TV 14

NOOK Settings

NOOK Settings provides access to the configuration settings for NOOK Library, NOOK Shop (e.g., credit cards and gift cards), and other NOOK features.




View NOOK Account Information

To View Account information:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **My Account** to view:
 - The email address associated with the owner's Barnes & Noble or NOOK account
 - The Profile name associated with the owner
 - The country of residence.



Configure the NOOK Library Widget

To select the type of content displayed by the NOOK Library widget on the Home screen:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Library widget** and customize the options.
 - By default, the widget displays just one issue or episode of any given magazine, TV show, newspaper, or catalog. Tap  **More options** to change how many will display.
 - To hide selected content, such as a particular book or app from the widget tap **Hide selected content item** and tap the item you want to hide.



Manage Credit Cards

To change the credit card associated with your Barnes & Noble or NOOK account:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Shop & Purchases** > **Credit Cards**.
3. If you already have a credit card associated with your account, tap the **Change** button. Otherwise, tap **Add New Credit Card**.
4. Enter the information for the card you want to associate with your account, and tap **Submit**.



Manage Gift Cards

To add a gift card to your account:



1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Shop & Purchases** > **Gift Cards**.
3. Tap **Add Gift Card**.
4. Enter the Card or Certificate Number and the PIN, and tap **Submit**.

Manage Shop Controls



To redeem an access code for NOOK content:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Shop & Purchases** > **Redeem Access Code**.
3. Enter the 13-digit access code and tap **Add Now**.

To clear the NOOK Search history of recent searches:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Shop & Purchases** > **Clear Search History**.
3. Tap **OK**.



To clear your browsing history from the NOOK Shop:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Shop & Purchases** > **Clear Browsing History**.
3. Tap **OK**.

Configure Adobe DRM Settings

DRM stands for Digital Rights Management, a system for managing publication and distribution rights for digital content. To gain authorized access to content protected with Adobe DRM on your NOOK, you need to obtain a free Adobe ID from Adobe and to enter that ID on your NOOK.


Once you have your Adobe ID:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader** > **Adobe DRM Settings**.
3. Tap **Add Adobe ID** and enter the email address and password for your Adobe ID.
4. Tap **OK**.

NOOK Search

The NOOK Search app lets you quickly search your Library and the NOOK Shop.

The **NOOK Search** app appears by default on your Home screen.

1. From a Home screen, tap  **NOOK Search**.
2. Type in the search field at the top of the screen. As you type, your NOOK displays suggestions for matching words and phrases in a pop-up window.
3. When you see the word or phrase you are searching for, tap it. If the word or phrase appears with a shopping bag icon next to it, tapping the selection searches for the word or phrase in the NOOK Store.

Sideloading Files

Sideloading means transferring files from your personal computer to your NOOK over the USB cable.

Note: If your personal computer is a Mac, you will need to install a free software program, Android File Transfer (AFT), on your computer before you can transfer files to and from your NOOK. AFT is available here: <https://www.android.com/filetransfer/>. If your computer is a PC, it will automatically detect your NOOK and install the software drivers it needs, if they are not already installed.

To sideload content:

1. Connect your NOOK's USB cable to a USB port on your computer.
2. Connect the other end of the cable to your device's Charger/Accessory Port on the bottom edge of your NOOK.

Once you have connected your NOOK to your computer, you will be able to access your NOOK's storage as though it were another drive connected to your computer. The My Files subfolder folder in the NOOK folder is for personal files you have not purchased through the NOOK Store. For example, if you have created PDFs on your computer and want to view them on your NOOK, you can drag them to the My Files folder.

3. Select the files you want to transfer from your computer, then drag and drop them from your computer to the My Files subfolder on your NOOK.
4. Once you finish sideloading the files you want to transfer, disconnect your NOOK from your computer by using your computer's file system to eject your NOOK as if you are ejecting a disk. Disconnect the USB cable.
5. To view your personal files once you have copied them to the My Files folder, open your NOOK Library on your device and scroll down to the My Files section of your Library.

Note: To view the amount of storage available on your NOOK, open the Settings app, tap the General tab, and tap **Storage** in the menu on the left.



Note: You can also transfer files to your NOOK using Dropbox or any other file-sharing app you have installed on your device.

Dictionaries

Your NOOK includes Merriam-Webster's Collegiate® Dictionary, Eleventh Edition. You can download and install free foreign-language dictionaries as well. Only one dictionary can be active at a time.



To download a foreign language, make sure your NOOK is connected to a Wi-Fi network.

Download Dictionaries

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader** > **Dictionary**.
3. Tap **Download** beside the language you want to add.
4. Once the dictionary has been downloaded, tap it to select it as the active dictionary.

Remove Dictionaries

To remove a dictionary:

1. From a Home screen, tap  **Apps** >  **NOOK Settings**.
2. Tap **Reader** > **Dictionary**.
3. Tap **Remove** beside the language you want to remove.

NOOK Legal Information

To read the NOOK Device Terms of Service, the NOOK Store Terms of Service, and the NOOK Privacy Policy, open the NOOK Settings app and tap Legal Information. Your NOOK displays links to popup windows with each of these documents.

To view NOOK legal information online, visit: [NOOK.com/legal](https://www.nook.com/legal).

Applications

The Apps list displays all applications installed on your device, both preloaded apps and apps you download and install yourself.


Learn how to change the way apps appear, organize apps into folders, and uninstall or disable apps.

Apps List

The Apps list shows all preloaded apps and apps that you downloaded. You can uninstall, disable, or hide apps from view.



Shortcuts to apps can be placed on any of the Home screens. For more information, see [Add a Shortcut to a Home Screen](#).

Access Applications

1. From a Home screen, tap  **Apps**.
2. Tap an application's icon to launch it.
3. To return to the main Home screen, press the **Home** key.

Download and Install New Apps

Find new apps to download and install on your device.




-  **Play Store**: Download new apps from the Google Play store. Visit play.google.com/store/apps to learn more.
-  **Galaxy Apps**: View and download Samsung apps that are optimized for use with Galaxy devices. Visit samsung.com/levant/apps/mobile/galaxyapps to learn more.

Uninstall or Disable Apps



You can uninstall or disable apps you download and install.

- Preloaded apps cannot be uninstalled.
- Apps that are disabled are turned off and hidden from view.

To uninstall or disable an app:

1. From a Home screen, tap  **Apps**.
2. Tap **EDIT**. Apps that can be uninstalled or disabled show  **Uninstall/Disable** on their icon.
3. Tap  **Uninstall/Disable** and follow the prompts to either uninstall or disable the app.

To enable apps after disabling them:


1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Swipe to the **DISABLED** screen, which only displays if you have disabled apps.
3. Tap the app you want to enable, and tap **ENABLE**. The app displays again in the Apps list.

For more information, see [Disabled Services](#).

Organize Your Apps

The Apps icons can be organized into folders and rearranged in a custom order.



Change the Order Apps Are Listed

1. From a Home screen, tap  **Apps**.
2. Tap **EDIT**.
3. Touch and hold an app shortcut or folder and drag it to a new location.
4. Tap **DONE** when finished.

To alphabetize your apps:


- ▶ From a Home screen, tap  **Apps** > **A-Z**.

Use Folders to Organize Apps

1. From a Home screen, tap  **Apps** > **EDIT**.
2. Touch and hold an app shortcut and drag it on top of another app shortcut until a highlighted box displays.
3. Release the app shortcut to create the folder.
 - Tap **Enter folder name** to name the folder.
 - Tap  **Palette** to change the folder color.
4. Tap anywhere outside of the folder to close it.
 - To add more apps, touch and hold an app shortcut and drag it to the folder.
5. Tap **DONE** when you are finished.

Remove Folders

Remove folders from an Apps screen without deleting the apps inside.

1. From a Home screen, tap  **Apps** > **EDIT**.
2. Tap the folder.
3. Tap **Delete folder**, and then tap **DELETE** to confirm.
4. Tap **DONE**.

Apps inside the folder are listed at the end of the Apps list.

NOOK Applications

The following NOOK applications are preloaded on your device.



Current Read

Tap to open the book or magazine you are currently reading.



NOOK Apps

The NOOK Apps app displays the NOOK apps you have purchased that are supported on the Samsung Galaxy Tab S NOOK.

If you have not purchased any NOOK apps yet, the NOOK Apps app displays a shortcut button that takes you directly to the Apps section of the NOOK Store.




NOOK Highlights and Notes

This application shows all highlights and notes you make in your books.



NOOK Home

View NOOK CHANNELS, books picked for you based on recent library activity, New York Times bestsellers, new releases, and shop departments.

Tap  in the upper-left corner of most NOOK screens to access Current Read, Home, Shop, Library, Messages, and Settings.



NOOK Library

Tap the NOOK Library app to open your NOOK Library. In the Library, you can see all your books, periodicals, TV shows and movies, and catalogs. You can also see all the NOOK apps you have purchased that are supported on the Samsung Galaxy Tab S NOOK.



NOOK Search

The NOOK Search app lets you quickly search your Library and the NOOK Shop.



NOOK Settings

NOOK Settings provides access to the configuration settings for NOOK Library, NOOK Shop (for example, credit cards and gift cards), and other NOOK features.

Note: To read the NOOK Device Terms of Service, the NOOK Store Terms of Service, and the NOOK Privacy Policy, open the NOOK Settings app and tap **Legal**. Your NOOK displays links to pop-up windows with each of these documents.



NOOK Shop

To reach the NOOK Store, launch the NOOK Shop app or tap the shopping bag icon at the top of the screen in any other NOOK app.

Google Applications

Enjoy these applications from Google.

Note: Certain applications require a Google Account. Visit google.com to learn more.



Chrome

Use Chrome to browse the Internet and bring your open tabs, bookmarks and address bar data from your computer to your tablet.

Visit google.com/chrome/browser/mobile to learn more.



Drive

Open, view, rename, and share your Google Docs and files.

Visit drive.google.com to learn more.



Gmail

Send and receive email with Gmail, Google's web-based email service.

Visit gmail.com to learn more.



Google


Search not only the Internet, but also the apps and contents of your device.

Google Now

Google Now works in the background to collect information you regularly look up and organize it into convenient cards that appear when you need them.

Visit google.com/landing/now to learn more.

► Press and hold the **Home** key.

Note: When Google Now is enabled, you can also access it by tapping  **Google**.



Google Settings

Quickly and easily change Google app settings to suit your preferences.

Note: You must be signed in to the application in which you want to configure.



Hangouts

Hangouts is an online place to meet friends and family, share photos, and host video calls.

Visit google.com/hangouts to learn more.



Maps

Use Google Maps to find your current location, get directions, and other location-based information.

Visit google.com/maps to learn more.

Note: You must enable location services to use Maps. For more information, see [Location](#).



Photos

This application automatically backs up your photos and videos to your Google account.

Visit photos.google.com to learn more.



Play Movies & TV

Watch movies and TV shows purchased from Google Play. You can stream them instantly or download them for viewing when you are not connected to the Internet. You can also view videos saved on your device.

Visit play.google.com/about/movies to learn more.



Play Music

With Google Play Music, you can play music and audio files on your device.

Visit play.google.com/about/music to learn more.



Play Store

Find new apps, movies and TV shows, music, books, magazines, and games in Google Play store.

Visit play.google.com/store to learn more.



Voice Search

Use voice commands to search the web with Google.



YouTube

View and upload YouTube videos right from your device.

Visit youtube.com to learn more.

Microsoft Applications

These Microsoft applications are also preloaded on your device.



Excel

The Excel app provides a core experience for viewing, creating and editing documents on tablets with a screen size of 10.1 inches or smaller. You can unlock the full Excel experience with an Office 365 subscription.



OneDrive

OneDrive gives you free online storage for all your personal files so you can get to them from your Android device, computer, and any other devices you use.



OneNote

You can stay organized using text, pictures, or audio notes. Create Quick Notes or review and edit shared OneNote notebooks using OneDrive.



PowerPoint

The PowerPoint app provides a core experience for viewing, creating and editing documents on tablets with a screen size of 10.1 inches or smaller. You can unlock the full PowerPoint experience with an Office 365 subscription.



Skype

Use free Skype to hold video and voice calls, as well as send instant messages to anyone around the world. Just open the app and start using it.



Word

The Microsoft Word app provides a core experience for viewing, creating and editing docs on tablets with a screen size of 10.1 inches or smaller. You can unlock the full Word experience with an Office 365 subscription.

Additional Applications

There are also additional apps, including several Samsung apps, preloaded on your device.



Milk Music

Exclusive to Galaxy owners, Milk Music is a radio service that gives you more of the music you love, curated by top DJs and industry pros and all for free.



Samsung+

Gain all the benefits of owning a Samsung Galaxy device and to get any guidance and support you need along the way.






SideSync 3.0

SideSync is a PC-Mobile solution that enables the screens, windows, and data to be shared easily between a PC and Samsung Android Device.

Calculator

The Calculator provides basic and advanced arithmetic functions.

Basic Operation

1. From a Home screen, tap  **Apps** >  **Calculator**.
2. Enter the first number using the numeric keys.
3. Tap the appropriate arithmetic function key.
4. Enter the next number.
5. To view the result, tap the  **Equals** key.

Additional Functions

To clear the results:

- ▶ Tap  **Clear**.

To clear the calculator history:

- ▶ Tap **CLEAR HISTORY**.




To copy all or part of the calculation to the clipboard:

- ▶ Touch and hold an entry in the display field.



Calendar

Manage your calendar events and tasks.



Create an Event

1. From a Home screen, tap  **Apps** >  **Calendar**.
2. Tap  **Add** to add an event.
3. Enter details for the event, and then tap **SAVE**.

Delete an Event




1. From a Home screen, tap  **Apps** >  **Calendar**.
2. Tap an event to view it, and then tap **DELETE**, and then confirm by tapping **DELETE**.

Share an Event



1. From a Home screen, tap  **Apps** >  **Calendar**.
2. Tap an event to view it.
3. Tap **SHARE** and tap a sharing format.
4. In the Share as window, tap a sharing method and follow the prompts.

Create a Task

Tasks are items you add to the calendar to be accomplished on a certain day. A task appears as a checklist item and is removed once you mark the task as complete.



1. From a Home screen, tap  **Apps** >  **Calendar**.
2. Tap **TASKS**.
3. Tap the **Enter new task** field and type a name for the task.
4. You can choose to set the task for **TODAY**, **TOMORROW**, or tap the  **Expand** icon to view and set the following options:
 - **Due date:** Tap the **ON/OFF** switch to select a date on the calendar for the task.
 - **Reminder:** Tap to set a reminder alert.
 - **Notes:** Tap to save a note with your task.
 - **Priority:** Tap to assign a priority to the task.
5. Tap **SAVE** to save the task.

Delete a Task

1. From a Home screen, tap  **Apps** >  **Calendar**.
2. Tap **TASKS**.
3. Tap the checkbox by the task to mark it as complete and remove it from the calendar.
4. To delete the task permanently, tap the task to open it, and then tap **DELETE**.


Calendar Settings

These settings allow you to modify settings associated with using the Calendar.

1. From a Home screen, tap  **Apps** >  **Calendar**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the prompts.

Camera




Take pictures and record videos with the Camera app.



- **Camera settings:** Tap to change camera settings.
- **Effect:** Tap to add an effect before taking a photo or video.
- **Gallery:** Tap to open the Gallery to view photos and videos.
- **Picture size:** Tap to change the picture size (resolution and screen ratio).
- **Record video:** Tap to record a video.
- **Shooting mode:** Tap to change the shooting mode.
- **Switch cameras:** Tap to switch between the rear and front cameras.
- **Take a picture:** Tap to take a picture.
- **Timer:** Tap to set the camera timer.

Take Pictures



Take pictures with your device's front or rear camera, or combine shots with Dual mode.

1. From a Home screen, tap  **Apps** >  **Camera**.
2. Using the display screen as a viewfinder, compose your shot by aiming the camera at the subject. While composing your picture, use the onscreen options or these gestures:
 - Touch the screen with two fingers and pinch or spread them on the screen to zoom in and out.
 - Tap the screen to focus on the area you touched. When you tap the screen, a brightness scale displays. Slide the light bulb up or down to adjust the brightness.
3. If desired, before taking the photo, you can tap icons to access various camera options and settings. You can also touch the screen to move the focus field to the area you touch.
4. Tap  **Take picture** to take the picture.

Note: You can also press the **Volume** key up or down to take a picture. This is the default function of the Volume key while Camera is active. You can also set the Volume key to act as the video record key or as a zoom key.

Shooting Mode

Several visual effects are available. Modes differ by which camera is active (front or rear facing).

1. From a Home screen, tap  **Apps** >  **Camera**.
2. Tap **MODE** to view the following options. Each section indicates which camera (front or rear) the modes are available for.

Both cameras

- **Virtual shot:** Create multi-directional views of objects.
- **Download:** Download additional shooting modes from the Galaxy Apps store.




Rear camera

- **Auto:** Allow the camera to evaluate the surroundings and determine the ideal mode for the picture.
- **Pro:** Manually adjust the ISO sensitivity, exposure value, white balance, and color tone while taking pictures.
- **Panorama:** Create a linear image by taking pictures in either a horizontal or vertical direction.
- **HDR (Rich tone):** Save the picture in HDR (rich tone) only.
- **Shot & more:** Use various functions with your burst shots after you take them, such as best photo, best face, drama, eraser, and panning shot.
- **Dual camera:** Take pictures and record videos in a variety of styles using the front and rear cameras at the same time.

Front camera

- **Selfie:** Take selfie shots and apply various effects, such as an airbrushed effect.
- **Interval shot:** Select the best pictures from a series of continuous shots taken at set intervals.

Camera Settings

1. From a Home screen, tap  **Apps** >  **Camera**.
2. Quick settings are listed across one side of the camera view finder. Available options vary depending on the camera or recording mode used. Default settings include:
 - **Picture size:** Select a resolution. Use higher resolution for higher quality. Higher resolution pictures take up more memory.
 - **Beauty:** Take a picture with lightened faces for gentler images (front camera only).
 - **Timer:** Take time-delayed pictures or videos.
 - **EFFECT:** Add special graphical effects.
3. Tap  **Settings** to configure settings for Camera. Available options vary depending on the camera/recording mode used.

Both cameras

- **Video size:** Select a resolution. Use higher resolution for higher quality. Higher resolution videos take up more memory.
- **View mode:** Choose between standard and full screen view mode.
- **Grid lines:** Display viewfinder grid lines to help composition when selecting subjects.
- **Location tags:** Attach a GPS location tag to the picture.
- **Review pictures:** Set to show pictures after taking them.
- **Storage location:** Choose to store your photos to your device or optional memory card.
- **Volume keys function:** Use the Volume key as the camera key, the record key, or as a zoom key.
- **Reset settings:** Reset the camera settings.

Rear camera



- **Video stabilization:** Activate anti-shake. Anti-shake helps to keep the focus steady when the camera is moving.

Front camera

- **Gesture control:** Detect palm and automatically take a picture two seconds later.
- **Save pictures as previewed:** Save the self-portrait or self-recording as seen on the preview screen.

Clock

The Clock app offers features for keeping track of time and setting alarms.



1. From a Home screen, tap  **Apps** >  **Clock**.
2. Tap a tab to use a feature:
 - **ALARM:** Set an alarm to ring at a specific time.
 - **WORLD CLOCK:** View the time of day or night in other parts of the world. World Clock displays time in hundreds of different cities, within all 24 time zones around the world.
 - **STOPWATCH:** Measure intervals of time.
 - **TIMER:** Use a timer to count down to an event based on a preset time length (hours, minutes, and seconds).

Alarm

Set alarms by using the ALARM tab.




Create an Alarm

Create an alarm event. You can set one-time or recurring alarms, and choose options for how to be notified.

1. From a Home screen, tap  **Apps** >  **Clock**.
2. Tap the following items to configure an alarm:
 - **Date:** Choose the day for this alarm.
 - **Time:** Set a time for the alarm.
 - **Repeat weekly:** Choose when to repeat the alarm, if so desired.
 - **KEYPAD:** Tap to use a keypad to enter the alarm time.


- **OPTIONS:** Tap to view and set the following options:
 - **Volume:** If you have chosen an alarm type that includes sound, drag the slider to set the volume of the alarm.
 - **Alarm tone:** If you have chosen an alarm type that includes sound, choose a sound to play for the alarm.
 - **Snooze:** Allow snoozing, and set interval and repeat values for the alarm while snoozing.
 - **Increasing volume:** When on, the alarm starts playing a tone at a low volume at an interval before the alarm time, and slowly increases in volume. Available when you have chosen an alarm type that includes sound.
 - **Alarm name:** Enter a name for the alarm.
3. Tap **SAVE** to save the alarm.

Delete an Alarm

1. From a Home screen, tap  **Apps** >  **Clock**.
2. Find the alarm in the alarm list (under the **Alarm** tab), and then tap  **Delete** in the upper right corner of the alarm entry.



World Clock

The world clock lets you keep track of the current time in multiple cities around the globe.

1. From a Home screen, tap  **Apps** >  **Clock**.
2. Tap **WORLD CLOCK**.
3. Touch and spin the globe to locate a city, and then tap a city. A pop-up displays information about the city.
4. Tap  **Add City**.
 - Repeat to add multiple cities.



Stopwatch

The stopwatch lets you time events down to the hundredth of a second.

1. From a Home screen, tap  **Apps** >  **Clock**.
2. Tap **STOPWATCH**.
3. Tap **START** to begin timing.
4. Tap **STOP** to stop timing.
 - Additional options include LAP to keep track of laps, RESUME to continue timing, and RESET to reset the stopwatch to zero.

Timer

The timer provides a countdown timer for up to 99 hours, 59 minutes, and 59 seconds.

1. From a Home screen, tap  **Apps** >  **Clock**.
2. Tap **TIMER**.
3. To set the length of the timer either tap the digits or tap **KEYPAD** to use a numeric keypad.
4. Tap **START** to begin the timer.
5. Tap either **PAUSE** or **CANCEL** to stop the timer.



Contacts

Store and manage your contacts with the Contacts app, which can be synchronized with a variety of your existing personal accounts, including Google, Email, Facebook, and your Samsung account.

For more information on connecting with and managing your accounts through your device, see [Accounts](#).



Manage Contacts

Access your list of contacts by using the Contacts app. To access your Contacts list:

- ▶ From a Home screen, tap  **Apps** >  **Contacts**.

Find a Contact

You can search for a contact or scroll the list to find one by name.








1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap the **Search** field, and then enter characters to find contacts that match.

– or –

Tap a letter on the side of the list to jump directly to that letter in the alphabetical list. You can also press and slide across the alphabetical list to select a letter with better precision.



Add a Contact

Use the following procedure to add a new contact.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap  **Create contact**, and then tap contact fields to enter information.
 - Choose a storage account for the contact. You can store the contact on the device or sync it with an account.
 - Tap  **Contact photo** to assign a picture to the new contact.
 - Enter a name, phone number, email address, and assign the contact to a group.
 - Tap  **Add** to enter additional entries.
 - Tap  **Remove** to remove an entry.
 - Tap  **Expand** for additional fields.
 - Tap the label to the right of an entry to choose a label for the field (for example, **Home** or **Work**).
 - Tap **ADD ANOTHER FIELD** to add additional contact information.
3. Tap **SAVE**.



Edit a Contact

When editing a contact, you can tap a field and change or delete the information, or you can add additional fields to the contact's list of information.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap the contact to display it, and then tap **EDIT**.
3. Tap any of the fields to add, change, or delete information.
4. Tap **SAVE**.




Share a Contact

When you share a contact, the contact's information is sent as a vCard file (.vcf). You can share a vCard via Bluetooth or Wi-Fi Direct, attach it to a message, or save it to a storage location.





1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap a contact to display it, and then tap **MORE** > **Share contact**.
3. Choose a sharing method and follow the prompts.

Link Contacts

When you have contacts from various sources (Gmail, Facebook, and so on), you may have multiple similar entries for a single contact. Contacts lets you link multiple entries into a single contact.



1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap the contact to display it.
3. Tap  **Link**.
4. Tap **LINK ANOTHER CONTACT**, and then select contacts to link to the original contact.
5. Tap **LINK**.

Unlink Contacts

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap the contact to display it.
3. Tap  **Link**.
4. Tap  **Separate** beside contacts to unlink them from the main contact.



Delete Contacts

You can delete a single contact or choose multiple contacts to delete.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Next to the Contacts heading, tap **MORE** > **Delete**.
3. Tap the contacts you want to delete, and then tap **DELETE**.

Create a Shortcut to a Contact





You can create a shortcut to a contact on a Home screen to access their information directly from a Home screen.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap the contact to display it.
3. Tap **MORE** > **Add shortcut to Home screen**. The new shortcut displays in an empty area of the Home screen.





Favorites

When you mark contacts as favorites, they are easily accessible from other apps. Favorites display together on the Favorites tab in Contacts.

Mark Contacts as Favorites

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap a contact to display it, and then tap  **Favorite** (the star brightens ).



Remove Contacts from Favorites

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap a contact to display it, and then tap  **Favorite** (the star dims .



Groups

You can use groups to organize your contacts. Your device comes with preloaded groups, and you can create your own. You might create a group for your family, for coworkers, or for a team. Groups make it easy to find contacts, and you can send messages to the members of a group.



Create a Group

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap **GROUPS**, and then tap **ADD**.
3. Tap fields to enter information about the group:
 - Tap **Group name** to enter a name for the new group.
 - Tap **Add member** and select contacts to add to the new group, and then tap **DONE**.
4. Tap **SAVE**.

Rename a Group



1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap **GROUPS**, and then tap a group.
3. Tap **MORE** > **Edit group** and enter a new name.
4. Tap **SAVE**.

Add Contacts to a Group

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap **GROUPS**, and then tap a group.
3. Tap **ADD**, and then tap the contacts you want to add.
4. Tap **DONE**.



Send an Email to a Group

You can send an email to members of a group.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap **GROUPS**, and then tap a group.
3. Tap **MORE** > **Send email**.
4. Tap contacts to select them or tap the **All** checkbox at the top of the screen to select all, and then tap **DONE**. You only see group members that have an email address in their records.
5. Choose an account and follow the prompts.



Delete a Group

Preset groups, such as Family, cannot be deleted.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap **GROUPS**.
3. Tap **DELETE**.
4. Tap the group category to open.
5. Tap the groups to select them or tap the **All** checkbox at the top of the screen to select all.
6. Tap **DELETE**.
7. Tap **Group only** to delete just the group or tap **Groups and members** to delete both the group and the contacts it contains.

Contact Settings



These settings allow you to modify settings associated with using the Contacts app.

1. From a Home screen, tap  **Apps** >  **Contacts**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the instructions.

Email



Use the Email app to view and manage all your email accounts in one application.

To access Email:




- ▶ From a Home screen, tap  **Apps** >  **Email**.

Configure Email Accounts

You can configure Email for most accounts in just a few steps.

1. From a Home screen, tap  **Apps** >  **Email**.
2. Follow the onscreen instructions to set up your email account.

To add another Email account:



1. From a Home screen, tap  **Apps** >  **Email**.
2. Tap **MORE** > **Settings** >  **Add account**.

The device communicates with the appropriate server to set up your account and synchronize your email. When complete, your email appears in the Inbox for the account.

Note: To configure email account settings at any time, tap **MORE** > **Settings**. Tap the email account to manage to display its settings.



View Multiple Email Accounts

You can view email you receive for all accounts on the **Combined view** screen or you can view email accounts individually.

1. From a Home screen, tap  **Apps** >  **Email**.
2. Tap the drop-down menu at the top left of the screen to view the current account mailbox.
3. Tap on the account name to view:
 - **Combined inbox:** View all email in a combined inbox.
 - **[Account Name]:** View email for only one email account.






Manage Your Inbox

There are several tools available from the Inbox screen.

- ▶ From a Home screen, tap  **Apps** >  **Email**.
 - Tap a message to read and reply or forward it.
 - Tap **SEARCH** to search for key words in your email inbox.
 - Tap **MORE** for additional message options like sorting, deleting, sharing and more.



Create and Send an Email

This section describes how to create and send an email using the Email app.

1. From a Home screen, tap  **Apps** >  **Email** >  **Compose**.
2. Tap the **To** field to manually add an email address, or tap  **Add Recipient** to select a recipient from Contacts or Groups.
 - If manually entering recipients, enter additional recipients by separating each entry with a semicolon (;). More recipients can be added at any time before the message is sent.
 - If adding a recipient from your Contacts, tap the contact to place a check mark then tap **DONE**. The contact is placed in the recipients field.
 - Tap  **More** to add Cc and Bcc fields.
3. Tap the **Subject** and **Message** fields and use the onscreen keypad to enter text.
 - Tap **ATTACH** to add Files, Images, Audio, and more to your email.
 - Tap **MORE** for additional email options.
4. Review your message and tap **SEND**.



Remove Email Accounts

To remove an email account:

1. From a Home screen, tap  **Apps** >  **Email**.
2. Tap **MORE** > **Settings**.
3. Tap the account you want to remove.
4. Tap **REMOVE**. Confirm by tapping **REMOVE** on the prompt.

Email Settings

These settings allow you to modify settings associated with using the Email app.

1. From a Home screen, tap  **Apps** >  **Email**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the onscreen instructions.



Galaxy Apps

Samsung Galaxy Apps is a free storefront that provides a quick and easy way to find and download apps that are compatible with your Galaxy device.



GALAXY Essentials is a collection of specially chosen applications available through Samsung Apps.

From GALAXY Essentials, you can access and download a collection of premium content, free of charge.

To access Galaxy Apps:

- ▶ From a Home screen, tap  **Apps** >  **Galaxy Apps**.

To access Galaxy Essentials:

1. From a Home screen, tap  **Apps** >  **Galaxy Apps**.
2. Swipe across the Galaxy Apps screen and then tap **Galaxy Essentials**.

– or –

Swipe across the Home screens and locate and tap the Galaxy Essentials widget.

3. Follow the instructions to download Galaxy Essentials apps specially chosen from Galaxy Apps.

Note: A Samsung account is required to purchase and download apps.



Gallery

View, edit, and manage pictures and videos.

Note: Some functions described in this section are only available if there are images or videos in the Gallery.

View Images and Videos

Launching Gallery displays available folders. When another application, such as Email, saves an image, a Download folder is automatically created to contain the image. Likewise, capturing a screenshot automatically creates a Screenshots folder.




1. From a Home screen, tap  **Apps** >  **Gallery**.
2. Tap the drop-down menu in the upper left corner, and then tap an option to choose the way items display.
 - To launch the Camera app, tap **CAMERA**.
 - In Albums view, you can create albums to organize your images. On the drop down menu, tap **Albums**, and then tap **MORE** > **Create album**.
3. Depending on the view mode selected, either tap an image or video to view it, or first tap an album or folder and then tap an image or video.
4. When viewing an image or video, you can scroll left or right to view the next or previous image or video.

Zoom In or Out



Use one of the following methods to zoom in or out on an image:

- Double-tap anywhere on the screen to zoom in or zoom out.
- Spread two fingers apart on any place to zoom in. Pinch the screen to zoom out.


Play Videos

1. From a Home screen, tap  **Apps** >  **Gallery**.
2. Tap a folder or category to open it.
3. Tap a video to view it.
4. Tap  **Play** to play the video.



Trim Segments of a Video

1. Select a video, and then tap the screen once to see the video options.
2. Tap  **Editor**, and then tap  **Trim**.
3. Use the sliders at the bottom of the screen to trim the video. Move the start bracket to the desired starting point, move the end bracket to the desired ending point.
4. Tap **EXPORT** to save the video. Modify the File name or Resolution, and then tap **EXPORT** to confirm the changes.

Edit Images



1. While viewing an image, tap the screen once to see the image options.
2. Tap  **Edit** to view and use the editing tools.

Delete Images

1. From a Home screen, tap  **Apps** >  **Gallery**.
2. Tap a folder or category to open it.
3. Tap **MORE** > **Edit**.
4. Tap images to select them.
5. Tap **DELETE**.

Share Images



Use one of the following methods:

1. From a Home screen, tap  **Apps** >  **Gallery**.
2. Tap a folder or category to open it.
3. Tap **MORE** > **Share**.
4. Tap images to select them, and then tap **SHARE**.
5. Tap a sharing service and follow the prompts to send the image or images.

Internet





Access the Internet with a fully-featured web browser.

To access the Internet:

- ▶ From a Home screen, tap  **Apps** >  **Internet**.

Command Keys

The following command keys are available on the browser window:

-  **Back** or  **Back** key to return to the previous page.
-  **Forward** to go forward to a recent page.
- **HOME** to display your Internet Home screen.
- **BOOKMARKS** to manage bookmarked pages, saved pages, and history.
-  **Refresh** to refresh or reload the current Web page.

View a Web Site

To view a web site:

- ▶ Tap the address field, enter the web address, and then tap **Go** on the keyboard.

To zoom in or out:

- ▶ Tap the screen twice or pinch the screen to zoom out. Stretch the screen to zoom in.

Browser Tabs

Use tabs to view multiple web pages at the same time.

To open a new tab:

- ▶ Tap  **Add tab**.

To close a tab:

- ▶ Tap  **Close tab**.

Bookmarks Page

The Bookmarks page stores Bookmarks, Saved pages, and History.

Save and Open Bookmarks

Bookmarking a web page saves the web address so that you can access it quickly.

To bookmark the current web page:

1. Tap **BOOKMARKS** > **ADD**.
2. Type a title for the bookmark and tap **SAVE**.

To open a bookmarked web page:

1. Tap **BOOKMARKS**.
2. Tap a bookmark entry.

Saved Web Pages

Saving a web page stores the web page content on your device so that you can access it offline.

To save the current web page:

- ▶ Tap **MORE > Save web page**.

To view saved web pages:

1. Tap **BOOKMARKS > SAVED PAGES**.
2. Tap a saved page to open it in the browser.

View History

To view a list of recently visited web pages:


- ▶ Tap **BOOKMARKS > HISTORY**.

Share a Web Page

You can share the current web page with others and even print using the Share option.

1. Tap **MORE > Share**.
2. Tap a sharing method and follow the prompts.

Secret Mode

Pages viewed in secret mode do not appear within your browser history or search history, and leave no traces (such as cookies) on your device.  **Secret** displays on Secret tabs.


Note: Any downloaded files remain on your device after you close a secret tab.

To open a new secret tab:

- ▶ Tap **MORE > New secret tab**.

Internet Settings








These settings allow you to modify settings associated with using the Internet app.

1. From a Home screen, tap  **Apps > Internet**.
2. Tap **MORE > Settings**.
3. Tap an option and follow the instructions.



Memo

Use the Memo app to write and save notes on your device.



Compose a Memo

1. From a Home screen, tap  **Apps** >  **Memo**.
2. Tap  **Create memo** and type a memo.
 - To change the category, tap  **Category**.
 - To insert an image into the memo, tap  **Image**.
 - To use your voice to insert text into the memo, tap  **Voice**.
 - To add tasks, tap  **Tasks**.
3. When finished creating your memo, tap **SAVE**.



Edit Memos

1. From a Home screen, tap  **Apps** >  **Memo**.
2. Tap a memo to view it.
3. Tap the content and make edits. When you are finished, tap **SAVE**.

Browse Memos


- ▶ From a Home screen, tap  **Apps** >  **Memo**.
 - Browse memo entries by swiping up or down.
 - To search for a memo, tap **SEARCH**.

Memo Options

1. From a Home screen, tap  **Apps** >  **Memo**.
2. While browsing memos, tap **MORE** for the following options:
 - **Edit:** Select notes to delete or move.
 - **Share:** Share memos.
 - **Manage categories:** Create and manage categories to organize your memos.
















Music Player

Listen to your favorite songs with the Music player. Navigate through your music library, play songs, and create customized playlists.



- **Favorite:** Tap to tag this song as a favorite.
- **Options:** Tap to view more options.
- **Playback controls:** Tap the icons to change shuffle or repeat modes, fast-forward or rewind, or play or pause the current song.
- **Playback position:** Drag to skip to another part of the current song.
- **Song length:** The length of the song.
- **Song queue:** Tap to view the current song list being played.
- **Sound quality and effects:** Tap for options to adjust sound effects.
- **Time elapsed:** The time elapsed for the current song.
- **Volume:** Tap to adjust the volume.

Listen to Music



1. From a Home screen, tap  **Apps** >  **Music**.
2. Tap a library category at the top of the screen to view your music files.
3. Scroll through the list of songs and tap an entry to begin playback.
4. While playing music, use these controls:
 - Tap  **Pause** to pause playback. To start playback again, tap  **Play**.
 - Tap  **Rewind** to move to the previous song. Touch and hold  **Rewind** to rewind through the song. Tap  **Fast-forward** to move to the next song. Touch and hold  **Fast-forward** to move forward through the song.
 - Tap the repeat button to control playback. Choose  **Repeat off** to play all songs once. Choose  **Repeat all** to repeat all songs. Choose  **Repeat 1** to repeat the current song.
 - Tap the shuffle button to control the order songs are played. Choose  **Shuffle off** to play songs in the order they appear in the list. Choose  **Shuffle on** to play songs in random order.
 - Tap  **Favorite** to mark a song as a favorite. Whenever a song is a favorite, the star is gold. Favorite songs are included in the Favorites playlist.
 - Tap  **Volume** to set the volume. You can also set volume by pressing the **Volume** key on the side of the tablet.

Note: When you close the Music screen, playback continues in the background, allowing you to listen to music while using other features of your tablet. When music is playing in the background, you can access playback controls from the Notification panel.

My Files








Access files stored on your device, including images, videos, songs, and sound clips.


To view files in My Files:

1. From a Home screen, tap  **Apps** >  **My Files**.
2. Tap a category to view the relevant files or folders.
3. Tap a file or folder to open it.



Manage Files

Files stored in the device are organized into the following groups:



- **Recent files:** View recently accessed files.
- **Category:** Files are grouped into the following categories:
 -  **Images:** View image files.
 -  **Videos:** View video files.
 -  **Audio:** View audio files.
 -  **Documents:** View document files.
 -  **Download history:** View all apps and files that have been downloaded to the device.
- **Local storage:** View folders and files in their storage locations.
 -  **Device storage:** View folders and files located on the device.
 -  **SD card:** View folders and files located on an optional microSD memory card (not included).

- **Cloud storage:** Contains shortcuts to FTP servers or other cloud storage locations that you have added.
 -  **Google Drive:** Sign in to view folders and files located in your Google Drive account.



My Files Options

- ▶ From a Home screen, tap  **Apps** >  **My Files**. The following options are available:
 - **SEARCH:** Search for a file or folder.
 - **MORE:** Tap for the following options:
 - **Edit:** Edit files shown in Recent files.
 - **Clear recent file history:** Clear the Recent files category.
 - **Show/Conceal hidden files:** Show or conceal hidden files.
 - **STORAGE USAGE:** Tap to view memory information for your device.

Category Options

1. From a Home screen, tap  **Apps** >  **My Files**.
2. After tapping a category, the following options are available:
 - **SEARCH:** Search for a file in the selected category.
 - **VIEW AS:** Change the appearance of the files or folders.
 - **MORE:** Tap for the following options:
 - **Edit:** Select files or folders.
 - **Create folder:** Create a new folder (Local storage).
 - **Add shortcut:** Add a shortcut folder to the main My Files screen.
 - **Sort by:** Change the sort order of the files.
 - **Show/Conceal hidden files:** Show or conceal hidden files.

Options for Selected Files and Folders

1. From a Home screen, tap  **Apps** >  **My Files**.
2. Tap **MORE** > **Edit**.
3. Tap a file or folder to select it, and select one of these functions:
 - **DELETE:** Delete files or folders.
 - **MOVE:** Move files or folders to another folder.
 - **MORE:** Select one of the following options:
 - **Copy:** Copy files or folders to another folder.
 - **Rename:** Rename a file or folder. This option only appears when just one file or folder is selected.
 - **Add shortcut on Home screen:** Add a shortcut the Home screen.
 - **Compress:** Create a zip folder containing the selected files. This option only appears in Local Storage categories. A selected zip folder has the additional options of **Extract** and **Extract to current folder**.
 - **Details:** View details of the selected files or folders.

Smart Manager



Smart manager provides an overview of the status of your device's battery, storage, RAM, and system security. You can also automatically optimize your device's system resources.

Quick Optimization



The quick optimization feature improves device performance through the following actions:

- Identifying apps that use excessive battery power and clearing unneeded items from memory.
- Deleting unnecessary files and closing apps running in the background.
- Scanning for malware.

To use the quick optimization feature:


1. From a Home screen, tap  **Apps** >  **Smart Manager**.
2. Tap **CLEAN ALL**.

Using Smart Manager

1. From a Home screen, tap  **Apps** >  **Smart Manager**.
 - ▶ Tap each of the following for options:
 - **Battery:** Check the battery power and time remaining to use the device. For devices with low battery levels, conserve battery power by activating power saving features and closing apps that are consuming an excessive amount of battery power.
 - The usage time remaining shows the time remaining before the battery power runs out. Usage time remaining may vary depending on your device settings and operating conditions.
 - **Storage:** Check the status of used and available memory capacity. You can delete unused or unneeded files, and uninstall apps that you do not use any more.
 - **RAM:** Check the amount of available RAM. You can close background apps and reduce the amount of RAM you are using to speed up your device.
 - **Device security:** Check the device's security status. This feature scans your device for malware.



Video Player

Play and manage videos stored on your device.






- **Fast-forward:** Tap to skip to the next video. Touch and hold to fast-forward the current video.
- **File name:** The name of the video file.
- **More options:** Tap to view more options.
- **Move controls:** Tap to move the Video player controls to the right or to the left (landscape orientation only).
- **Pause or Play:** Tap to pause or play the current video.
- **Playback position:** Drag to skip to another part of the video.
- **Pop-up player:** Tap to open the video in the pop-up player window.
- **Rewind:** Tap to restart the video or skip to a previous video. Touch and hold to rewind the video.
- **Screen ratio:** Change the screen ratio.
- **Time elapsed:** The time elapsed for the current video.
- **Video length:** The total length of the video.
- **Video list:** See the current video playlist.
- **Volume:** Adjust the volume.

Access the Video Player

1. From a Home screen, tap  **Apps** >  **Video**.
2. Scroll through the videos stored on your device. After a few seconds, each video thumbnail begins playing a preview of the clip.
3. Tap a video to view it.






Use Pop-up Player

Multitask with Pop-up player by transforming your video player into a pop-up window. The video continues to play, and the pop-up player can be resized or moved anywhere on the screen.

1. From a Home screen, tap  **Apps** >  **Video**.
2. Tap a video to view it.
3. Tap  **Pop-up player** to continue playing the video in a floating window.
 - Drag the window to any location on the screen.
 - Use two fingers to pinch or spread to resize the floating window.

Change the Video Screen Size

You can change the size of the video during video playback.



1. From a Home screen, tap  **Apps** >  **Video**.
2. Tap a video to view it.
3. Tap the screen ratio icon to cycle through the screen size options:
 -  **Full**: The entire screen is used, which may cause some minor distortion.
 -  **Fit to screen**: The video is played in its original size.
 -  **Keep ratio**: The video is enlarged to fit the screen without becoming distorted.

Settings


Configure your device's connections and settings, add accounts, and customize the Home screen, apps, and features.

How to Use Settings




Access Settings

► From a Home screen, tap  **Apps** >  **Settings**.

– or –

From a Home screen, drag down from the Status bar to display the Notification panel, and then tap  **Settings**.

Using Settings

- Some options use an **ON/OFF** button to turn the option **ON** () or **OFF** () .
- For some options, you must tap a field, such as **Email address**, to display and set options.
- Some options are enabled or disabled by tapping a  checkbox. When enabled, a check mark displays. Tap the check mark to remove it and disable the option.



Categories of Settings

Settings are grouped into four categories.

- **Connections:** Wi-fi, Bluetooth, VPN, Mobile networks, and other connections.
- **Device:** Display, Sounds and notifications, Wallpaper, and other device settings.
- **Personal:** Accounts, Lock screen, Security, and other personal settings.
- **System:** Language and input, Date and time, Battery, Storage, and other system settings.

Search for Settings

If you are not sure exactly where to find a certain setting, you can use the Search feature.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **SEARCH**.
 - Enter a word or words in the Search field. As you type, settings that match display on the screen.
 - Tap an entry to go to that setting.



Wi-Fi

Wi-Fi is a term used for certain types of Wireless Local Area Networks (WLAN). Wi-Fi communication requires access to a Wireless Access Point (WAP).

Wi-Fi Direct creates a direct connection between two or more devices using Wi-Fi.



Turn Wi-Fi On or Off

Turning Wi-Fi on makes your device able to discover and connect to compatible in-range WAPs.



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on or off.

Wi-Fi Status Indicators



Status bar icons show your current Wi-Fi connection status:

- When Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP),  displays.
- If a Wi-Fi access point is available, but your device is not connected to it,  displays. It may also display if there is a communication issue with the target Wireless Access Point (WAP).

Scan and Connect to a Wi-Fi Network



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on. When Wi-Fi is turned on, your device automatically scans for available networks and displays them.
3. Tap the network you want to connect to. When you select an open network, you are automatically connected to the network. Otherwise, enter a password to connect.

Manually Connect to a Wi-Fi Network

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on.
3. Tap **MORE** > **Add network**.
4. Enter information about the Wi-Fi network:
 - Tap **Enter network name** to enter the name of the Wi-Fi network.
 - Tap the **Security** field and select a security option and enter your password.
 - Tap **Show advanced options** if you need to add advanced options such as IP settings and Proxy settings.
5. Tap **CONNECT** to store the new information and connect to your target WAP.



Wi-Fi Options

The Wi-Fi settings menu allows you to set up many of your device's advanced Wi-Fi services.


1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on.
3. Tap **MORE** for options:
 - **Add network**: Manually add a Wi-Fi network.
 - **WPS push button**: Set up a connection to a WPS (Wi-Fi Protected Setup) router or other equipment.
 - **WPS PIN entry**: View the PIN used by your device to set up a PIN-secured connection to a Wi-Fi router or other equipment (not configurable).
 - **Keep Wi-Fi on during sleep**: Specify when to disconnect from Wi-Fi.
 - **Always allow scanning**: Allow Google location service and other apps to scan for networks, even when Wi-Fi is turned off.
 - **Install network certificates**: Install authentication certificates.

Wi-Fi Direct

Wi-Fi Direct allows direct device-to-device connections via Wi-Fi, without having to connect to a Wi-Fi network.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on. Wi-Fi must be on to configure settings.
3. Tap **Wi-Fi Direct**. Your device automatically scans for nearby Wi-Fi Direct devices.
4. After scanning for devices, select a device, and then follow the prompts to complete the connection.

Wi-Fi Direct Status Indicator



When your device is connected to another device using Wi-Fi Direct,  displays in the Status bar.

Bluetooth


Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car Bluetooth systems, and Bluetooth-enabled computers, printers, and wireless devices.

Note: The Bluetooth communication range is approximately 30 feet.

Turn Bluetooth On or Off



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Bluetooth**, and then tap **ON/OFF** to turn Bluetooth on or off.

Bluetooth Status Indicator

When Bluetooth is turned on,  displays in the Status bar.

Scan for Bluetooth Devices



When you want to pair with another Bluetooth device, you can scan for nearby devices that are visible.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Bluetooth**, and then tap **ON/OFF** to turn Bluetooth on.
3. When Bluetooth is first turned on, it scans for nearby Bluetooth devices and displays them.
 - Tap **SCAN** to manually perform a new scan.

Pair Bluetooth Devices

The Bluetooth pairing process allows you to establish trusted connections between your device and another Bluetooth device.


Pairing between two Bluetooth devices is a one-time process. Once a pairing is created, the devices continue to recognize their partnership and exchange information without having to re-enter a passcode.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Bluetooth**, and then tap **ON/OFF** to turn Bluetooth on.
3. Make sure that the target device is discoverable so that your device can find it. Refer to the instructions that came with the device to find out how to set it to discoverable mode.
4. Tap **SCAN**. Your device starts scanning for Bluetooth devices within range.
5. When you see the name of the target device displayed in the Bluetooth devices section, tap the name. Your device then automatically tries to pair with the target device. If automatic pairing fails, enter the passcode supplied with the target device.

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth compatible devices.

Delete a Paired Device (Unpair)



When you unpair from a Bluetooth device, the two devices no longer recognize each other. To connect again, you have to pair the devices.

1. Verify your Bluetooth is active.
2. From the Bluetooth settings page, tap  **Settings** next to the previously paired device, and then tap **Unpair** to delete the paired device.

Flight Mode

Flight mode disconnects your device from all networks and turns off connectivity features, such as Wi-Fi and Bluetooth.

While in Flight mode, you can use other features, such as playing music, watching videos, and other offline applications.



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Flight mode**, and then tap **ON/OFF** to enable or disable the option.

Note: You can also enable Flight mode from the Device options menu. Press and hold the **Power** key, and then tap **Flight mode**.

Data Usage

Monitor your mobile data usage.

Note: Your service provider may account for data usage differently.



1. From a Home screen, tap  **Apps** >  **Settings** > **Data usage** for options:
 - **Data usage cycle:** Tap the drop-down menu, and then choose a time period for data usage. Data usage for the period displays on the graph, along with usage by application below.
 - **App usage:** View data usage by application.
2. Tap **MORE** for the following option:
 - **Restrict networks:** Select Wi-Fi networks that are mobile hotspots. You can restrict apps from using these networks, and you can configure apps to warn you before using these networks for large downloads.

More Connection Settings

This option displays additional connectivity information.

Printing

Print images and documents to Samsung printers and other compatible printers (not included).

1. From a Home screen, tap  **Apps** >  **Settings** > **More connection settings**.
2. Tap **Printing**.
3. Tap a print service and follow the prompts.



Note: Tap **Download plug-in** to install additional print service drivers.

Virtual Private Networks (VPN)



Set up and manage your Virtual Private Networks (VPNs).

Note: You must set a screen lock Pattern, PIN, Password, or Fingerprints before setting up a VPN. For more information, see [Lock Screen and Security](#).



Add a VPN

1. From a Home screen, tap  **Apps** >  **Settings** > **More connection settings**.
2. Tap **VPN**.
3. Tap **ADD VPN** and follow the prompts to set up your VPN.

Connect to a VPN



1. From a Home screen, tap  **Apps** >  **Settings** > **More connection settings**.
2. Tap **VPN**.
3. Tap the VPN, enter your log in information, and tap **CONNECT**.

Edit or Delete a VPN

1. From a Home screen, tap  **Apps** >  **Settings** > **More connection settings**.
2. Tap **VPN**.
3. Touch and hold the VPN that you want to edit or delete.

Ethernet

Manage your Ethernet connections.



1. From a Home screen, tap  **Apps** >  **Settings** > **More connection settings**.
2. Tap **Ethernet** and follow the prompts to connect to an Ethernet network.

Sounds and Notifications

Configure the sounds used to indicate notifications, screen touches, and other activities.

Sound Mode



You can switch between sound modes, while preserving the individual sound settings you have made.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **Sound mode**, and then choose a mode:
 - **Sound:** Your device uses the sounds and volume levels you have chosen in Sound settings for notifications and alerts.
 - **Mute:** Your device mutes all sounds and notifications.

Volume

Set the system volume level, and set default volume for notifications and other audio.

Tip: You can also set System volume from the Home screen by pressing the **Volume** key.



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **Volume**.
3. Drag the sliders to set the default volume for:
 - Notifications
 - Media
 - System

Sounds

Adjust sound levels and configure sound options for applications and notifications.



Default Notification Sound

Choose a sound for notifications, such as for new messages and event reminders.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **Sounds** > **Default notification sound**.
3. Tap a sound to hear a preview. Tap **OK** to select it.



Set Notification Sounds for Samsung Applications

Choose notification alerts for new messages, calendar events, and email.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notification** > **Sounds**, and then tap to configure each option:
 - **Calendar:** Configure event notifications.
 - **Email:** Configure email account notifications.

System Sounds

Set various other system sound options.



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notification** > **Sounds**, and tap to enable each option:
 - **Touch sounds**: Play tones when you touch or tap the screen to make selections.
 - **Screen lock sounds**: Play a sound when you unlock the screen.
 - **Keyboard sound**: Play a sound when the Samsung keyboard is tapped.

Sound Quality and Effects



Choose from advanced sound options to customize your audio experience.

Sound Quality

Find the best sound setting for your preferences.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notification** > **Sound quality and effects**.
3. Tap **Adapt Sound** and follow the prompts to customize your sound settings.



Sound Effects

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sound and notification** > **Sound quality and effects**.
3. Tap **ON/OFF** to enable each option:
 - **SoundAlive+**: Recreate the effects of rich surround sound.
 - **Tube Amp**: Simulate the soft timbre of a tube amplifier.

Do Not Disturb

This setting allows you to block all notifications and alerts. The options below determine what notifications can make sounds, and during what time periods you want to enter this mode.



To activate Do Not Disturb mode:

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **Do not disturb**.
3. Tap **ON/OFF** next to **Enable now** to enable this option.

Set Schedule



This option allows you to turn Do not disturb mode on and off automatically at scheduled times.

Note: Scheduling is not available if Do not disturb mode has been turned on manually.



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **Do not disturb**.
3. Tap **ON/OFF** next to **Enable as scheduled**, and set the Days, Start time, and End time.

Allow Exceptions

This option lets you customize what notifications are allowed while your device is in Do not disturb mode.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **Do not disturb**.
3. Tap **Allow exceptions**, and tap **ON/OFF** to enable the exceptions you want to allow.

App Notifications



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Sounds and notifications** > **App notifications**, and then choose an app to enable or disable notifications.

Display

Configure the tablet's display brightness, screen timeout delay, and other display settings.

Brightness



Adjust the screen brightness to suit your surroundings or personal preference. You may also want to adjust screen brightness to conserve battery power.

1. From a Home screen, tap  **Apps** >  **Settings** > **Display**.
2. Tap **Brightness** for options:
 - Tap **Auto** to allow the device to adjust brightness automatically.
 - To set a custom brightness level, clear the Automatic brightness check mark and drag the **Brightness** slider.

Note: You can also control Brightness from the Notification panel. Drag down the Status bar at the top of the screen to find the Brightness options.



Font Size and Style

You can set the font style and size for all text that displays on the screen.

1. From a Home screen, tap  **Apps** >  **Settings** > **Display**.
2. Tap **Font** to choose a font size and font style.
 - Drag the slider to adjust the font size.
 - Tap a font style to select a font, or tap **Download fonts** to find new fonts from Galaxy Apps.
3. Tap **OK** to set the font size and style.



Screen Timeout

Choose how long the display screen remains lit after you tap the screen or press any key.

1. From a Home screen, tap  **Apps** >  **Settings** > **Display**.
2. Tap **Screen timeout** and choose a time period.



Smart Stay

Using the front camera to detect your face, the screen does not time out as long as you are facing the screen.

1. From a Home screen, tap  **Apps** >  **Settings** > **Display**.
2. Tap **Smart stay**, and tap **ON/OFF** to turn the feature on.

Screen Mode

Choose a screen mode to match your type of viewing. You can choose to have the device automatically adapt the display depending on the type of image being displayed, and other criteria such as battery level.






1. From a Home screen, tap  **Apps** >  **Settings** > **Display**.
2. Tap **Screen mode**, and then choose a screen mode.
 - To have your device automatically optimize the display to match the type of image being displayed and other criteria, such as battery level, tap **Adaptive display**.

– or –

Choose a specific type of screen mode based on what you are viewing.



Daydream

The Daydream setting controls what the screen displays when the device is docked (dock not included), or while charging. You can choose to display colors, or display photos stored on your device.

1. From a Home screen, tap  **Apps** >  **Settings** > **Display**.
2. Tap **Daydream**. Tap **ON/OFF** to turn Daydream on. Configure options:
 - **Colors**: Tap the selector to display a changing screen of colors.
 - **Photo Frame**: Display pictures in a photo frame. Tap  **Settings** for options.
 - **Photo Table**: Display pictures in a photo table. Tap  **Settings** for options.
 - **Photos**: Display pictures from your Google Account. Tap  **Settings** for options.
3. Tap **MORE** for additional options:
 - **Preview**: See a demonstration of Daydream.
 - **Select when to daydream**: Select when your tablet can go into daydream mode.

Motions and Gestures

Control certain device actions by touching the screen with the palm of your hand or turning over the device.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Motions and gestures**.
3. Tap **ON/OFF** to enable each of the following:
 - **Mute**: Mute sounds and video by covering the screen or turning over the device.
 - **Palm swipe to capture**: Capture an image of the screen when you sweep your hand left or right across the screen.

Applications Settings

Manage settings for applications on your tablet.



Application Manager

You can download and install new applications on your device. Use Application manager settings to manage your downloaded and preloaded applications.

Warning: Because this device can be configured with system software not provided by or supported by Google or any other company, you operate this software at your own risk.

Memory Usage



See how memory is being used by Downloaded or Running applications.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Swipe across the screen to display **DOWNLOADED**, **SD CARD**, **RUNNING**, or **ALL** to display memory usage for that category of applications. If you have disabled applications, a **DISABLED** tab also displays.

The graph on the **RUNNING** tab shows used and free RAM.

Downloaded



Displays apps you have downloaded onto your device.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Tap **DOWNLOADED** to view a list of all the downloaded applications on your device.
 - To switch the order of the **DOWNLOADED** list, tap **MORE** > **Sort by size** or **Sort by name**.
 - To reset all of your application preferences, tap **MORE** > **Reset app preferences**.
3. Tap an application to view and update information about the application, including memory usage, default settings, and permissions. The following options are displayed:
 - **FORCE STOP:** Stop an app that is misbehaving. Restart your device if stopping an app, process, or service causes your device to stop working correctly.
 - **UNINSTALL/UNINSTALL UPDATES:** Delete the application from the device or uninstall updates made to apps that cannot be deleted.
 - **DISABLE:** Disable apps that cannot be deleted.
 - **Show notifications:** Tap the checkbox to enable or disable notifications from the app. Notifications display in the Status bar.
 - **MOVE TO SD CARD:** Move the app to an optional SD card (not included).
 - **CLEAR DATA:** Clear application data from memory.
 - **CLEAR CACHE:** Clear an application's temporary memory storage.

- **CLEAR DEFAULTS:** Clear an application's customization.
- **Permissions:** View information about the application's access to your device and data.



SD Card

Displays apps you have on your SD card.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Tap **SD CARD** to view a list of all the downloaded applications on your device.
 - To switch the order of the SD CARD list, tap **MORE** > **Sort by size** or **Sort by name**.
 - To reset all of your application preferences, tap **MORE** > **Reset app preferences**.
 - Tap an application to view and update information about the application, including memory usage, default settings, and permissions.

Running Services

View and control services running on your device.



1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Tap **RUNNING** to view a list of running services.
 - All the applications that are currently running on the device display.
 - The graph on the RUNNING tab shows used and free RAM.
3. Tap **SHOW CACHED PROCESSES** to display all the cached processes that are running. Tap **SHOW SERVICES IN USE** to switch back.

4. Tap one of the applications to view application information.
 - **STOP:** Stops the application from running on the device. This is usually done prior to uninstalling the application. (Not all services can be stopped. Stopping services may have undesirable consequences on the application or Android System.)
 - **REPORT:** Report failure and other application information.

Note: Options vary by application.

All Apps and Services



View and control all apps and services on your device.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Tap **ALL** to view a list of all the downloaded applications on your device.
 - To switch the order of the SD CARD list, tap **MORE** > **Sort by size** or **Sort by name**.
 - To reset all of your application preferences, tap **MORE** > **Reset app preferences**.
 - Tap an application to view and update information about the application, including memory usage, default settings, and permissions.

Disabled Services

View and configure disabled apps on your device.



Note: This screen only displays if you have disabled an app on the Apps screen.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Application manager**.
2. Tap **DISABLED** to view a list of applications you have disabled.
3. To switch the order of the DISABLED list, tap **MORE** > **Sort by size** or **Sort by name**.
4. To reset all of your application preferences, tap **MORE** > **Reset app preferences**.
5. Tap an application to view and update information about the application, including memory usage, default settings, and permissions. The following options are displayed:
 - **FORCE STOP:** Stop an app that is misbehaving. Restart your device if stopping an app, process, or service causes your device to stop working correctly.
 - **ENABLE:** This moves the application back to the Apps screen.
 - **Show notifications:** Tap the checkbox to enable or disable notifications from the app. Notifications display in the Status bar.
 - **MOVE TO SD CARD:** Move this app to your microSD card.
 - **CLEAR DATA:** Clear application data from memory.
 - **CLEAR CACHE:** Clear an application's temporary memory storage.
 - **CLEAR DEFAULTS:** Clear an application's customization.
 - **Permissions:** View information about the application's access to your device and data.

Note: Options vary by application.



Default Applications

If you have multiple applications of the same type, such as email apps, you can select one app to be the default.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications** > **Default applications**.
2. Your defaults are displayed.
3. To clear defaults you have set up, tap **CLEAR**.

Application Settings

Shortcuts to the settings for various apps are available in one convenient location.

1. From a Home screen, tap  **Apps** >  **Settings** > **Applications**.
2. Tap one of the following to display the settings for the selected app:
 - Calendar
 - Camera
 - Contacts
 - Email
 - Internet
 - Music
 - Weather

Users



Share your tablet with multiple people by creating User accounts.

Users have their own space, which they can customize with their own apps, wallpaper, and so on. Users can also adjust tablet settings that affect everyone, such as Wi-Fi.




Restricted profiles allow only limited access to apps and content.

Set Up User Profiles

Set up user profiles and then select one when unlocking the device to use personalized settings.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Users**.
3. Tap **Add user or profile** and follow the instructions to set up a new user or profile.

Delete a User or Profile

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Users**.
3. Tap  **Remove** to delete the user or profile.

Note: Only the device owner can delete other users or profiles.


Note: Deleting a user's profile removes the user account from the device entirely. This includes the NOOK profile, as well as the user's Google account, Samsung account, and any other local accounts associated with the user.

Switch User Profiles

To access the device with a user profile:

- ▶ From a Lock screen, tap  **Manage Users**, and then tap a profile.

– or –

Swipe down on the Status bar to display the Notification panel and tap  **Manage Users**, and then tap a profile.

Change User Account Nicknames and Photo IDs



Each user's profile includes a personal contact entry, listed as ME in Contacts.

To change their ID photo and name, each user can edit their personal Contact entry. For more information, see [Edit a Contact](#).

Wallpaper

Change the look of the Home and Lock screens with wallpaper.



You can display a favorite picture or choose from preloaded wallpapers.

1. From a Home screen, tap  **Apps** >  **Settings** > **Wallpaper**.
2. Tap **HOME SCREEN**, **LOCK SCREEN**, or **HOME AND LOCK SCREENS**.
3. Tap a image to preview it, and then tap **SET AS WALLPAPER**.
 - Tap **From Gallery** for additional wallpapers.

Lock Screen and Security

Secure your device and protect your data with Lock Screen and Security settings.

Set a Screen Lock

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Screen lock type** to select a screen lock and level of security:
 - **Swipe**: Swipe the screen to unlock it. This option provides no security.
 - **Pattern**: A screen unlock pattern is a tap gesture you create and use to unlock your device. This option provides medium security.
 - **PIN**: Select a PIN to use for unlocking the screen. This option provides medium to high security.
 - **Password**: Create a password for unlocking the screen. This option provides high security.
 - **Fingerprints**: Use fingerprint recognition to unlock the screen. This option provides medium to high security.
 - **None**: Never use a Lock screen.
3. If you choose a secured lock screen option, select your notification settings:
 - **Show content**
 - **Hide content**
 - **Do not show notifications**

4. Choose a screen lock option:
 - **Show information**: Show the dual clock, or information such as the weather information, on the lock screen.
 - **Notifications**: Show notifications on the Lock screen.
 - **Unlock effect**: Set the visual effect used when unlocking the screen. (This option is available with Swipe only.)

After setting a Pattern, PIN, Password, or Fingerprints screen lock type, additional options are available:

- **Secure lock settings**: Set the following secure lock functions:
 - **Make pattern visible**: Display the pattern as you draw it. (This option is available with Pattern only.)
 - **Lock automatically**: Set the time after the screen is turned off to enable the screen lock.
 - **Lock instantly with power key**: Tap **ON/OFF** to enable or disable locking the screen immediately when pressing the Power key.
 - **Smart Lock**: Set your tablet to stay unlocked when you have trusted devices connected or when it's in a trusted place.

Note: Options vary based on the screen lock type.

Fingerprints



Use fingerprint recognition as an alternative to entering passwords in certain apps.

You can also use your fingerprint to verify your identity when logging in to your Samsung account.

Note: Fingerprint recognition uses the unique characteristics of each fingerprint to enhance the security of your device. The likelihood of the fingerprint sensor confusing even small areas of two different fingerprints is very low. **But, in rare cases, the sensor may recognize a fingerprint that is similar to a registered fingerprint.**



Register a Fingerprint

You can register up to 4 fingerprints. A password is also set up as an alternative to your fingerprint.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Fingerprints**.
 - To add a fingerprint, tap **Add fingerprint** and follow the instructions to register a fingerprint and password.
 - To rename a fingerprint, touch and hold the fingerprint, and then tap **RENAME**.
 - To delete a fingerprint, touch and hold the fingerprint, and then tap **REMOVE**.



Change Backup Password

You can change the backup password for your fingerprint.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Fingerprints**.
3. Tap **Change backup password** and enter a new password.



Fingerprint Verification

Fingerprint verification can be used for other accounts accessed from your device.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Fingerprints**.
 - **Web sign-in:** Access your online accounts using your fingerprint.
 - **Verify Samsung account:** Verify your identity using your fingerprint when logging in to your Samsung account.

Device Security

Configure security for your device.



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Device security**.
3. Tap **Install My KNOX** to activate KNOX active protection on your device.

Find My Mobile

Protect your device from loss or theft allowing your device to be locked, tracked, and for your data to be deleted remotely.



- ▶ To access your device remotely, visit findmymobile.samsung.com.

Note: You must sign up for a Samsung account and enable Google location service to use Find My Mobile.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Find My Mobile**.
3. Enter your Samsung account password or, if you are not logged in to your Samsung account, tap **Add account** and follow the prompts.
4. The following options are available:
 - **Remote controls:** Tap to activate or deactivate Remote controls, which allows you to access your device remotely.
 - **Google location service:** Tap to activate or deactivate Google location service. This service must be on in order to find your device.

Unknown Sources

Enable installation of non-Google Play applications.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Unknown sources** to enable this option.



Warning: Enabling installation of third-party applications can cause your device and personal data to be more vulnerable to attacks by unknown sources.

Other Security Settings

Change other security settings, such as those for security updates and credential storage.



Encryption

Require a numeric PIN or password to decrypt your device each time you power it on or encrypt the data on a memory card (not included) each time it is connected.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Other security settings**.
 - **Encrypt device:** Follow the prompts to encrypt all data on your device.
 - **Encrypt external SD card:** Follow the prompts to encrypt all data on a memory card (not included).



Passwords

Display password characters briefly as you type them.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Other security settings** > **Make passwords visible** to turn the feature on.



Security Update Service

Automatically receive security updates.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Other security settings** for the following Security update service options:
 - **Security policy updates:** Automatically or manually check for security policy updates.
 - **Send security reports:** Send security reports to Samsung via Wi-Fi for threat analysis.



Device Administration

Manage your device administrators and application installation privileges.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Other security settings** > **Device administrators**.
3. Tap **Android Device Manager** to allow it to lock or erase a lost device.



Credential Storage

Manage your security certificates. If a certificate authority (CA) certificate gets compromised or for some other reason you do not trust it, you can disable or remove it.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Other security settings** for the following Credential storage options:
 - **Storage type:** Select a storage location for credential contents.
 - **View security certificates:** Display certificates in your device's ROM and other certificates you have installed.
 - **Install from device storage:** Install a new certificate from storage.
 - **Clear credentials:** Erase the credential contents from the device and reset the password.

Advanced Security Settings

Use these options to configure advanced security settings.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Lock screen and security** > **Other security settings** for the following Advanced options:
 - **Trust agents:** Perform selected actions when trusted devices are connected. (Only available when a secure screen lock is set.)
 - **Pin windows:** Pin an app on your device screen, preventing access to other features of your device.
 - **Usage data access:** View the applications that can access your device's usage history.
 - **Notification access:** View the applications that can access notifications you receive on your device.

Note: To view Trust agents, set up a screen lock (PIN, Password, or Pattern). For more information, see [Set a Screen Lock](#).

Privacy



Choose from various modes designed to hide personal content from being accessed by anyone else using your device, or to aid you in an emergency.

Note: A secure screen lock (Pattern, PIN, Fingerprint, or Password) is required to use Private Mode.

Location



Some apps, such as Google Maps, may require one or more location services be turned on for full functionality.

Locating Method

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Privacy** > **Location**.
3. Tap **ON/OFF** to turn on Location services.
4. Tap **Locating method** to select how your location is determined:
 - **GPS and Wi-Fi:** Use GPS and Wi-Fi networks.
 - **Wi-Fi only:** Use Wi-Fi only (no GPS).
 - **GPS only:** Use GPS only.



Recent Location Requests

Apps that have requested your location are listed under Recent location requests.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Privacy** > **Location**.
3. Tap **ON/OFF** to turn on Location services.
4. Tap an entry under **Recent location requests** to view the app's settings.

Location Services

Google uses Location Reporting to store and use your device's most recent location data. Google apps, such as Google Maps, can use this data to improve your search results based on places that you have visited.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Privacy** > **Location**.
3. Tap **ON/OFF** to turn on Location services.
4. Tap **Google Location Reporting** and sign in to your Google Account for options.



Private Mode

Hide personal content from being accessed by anyone else using your device.

Private mode is only available for certain applications.

Note: A secure screen lock (Pattern, PIN, Fingerprint, or Password) is required to use Private Mode.

Set Up Private Mode



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Privacy** > **Private mode**.
3. Tap **ON/OFF** to turn Private mode on.
4. Select an access type, and then follow the prompts to configure it.
 - Tap **Auto disable** to automatically turn off Private mode when the screen turns off.

Using Private Mode

When using Gallery, Video, Music, My Files, or Internet, select items you want to move to Private, and then tap **MORE** > **Move to Private**.

Report Diagnostic Info



This feature sends diagnostic information about your tablet when you are having technical problems.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Privacy** > **Report diagnostic info**.
3. Tap **YES** to enable this feature or tap **NO THANKS**.

Accessibility

Accessibility services are special features that make using the device easier for those with certain physical disabilities.

Note: You can download additional accessibility applications from the Google Play store.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accessibility** for options:

Vision

- **Voice Assistant:** Speak feedback aloud to help blind and low-vision users.
 - Voice Assistant can collect all of the text you enter, except passwords, including personal data and credit card numbers. It may also log your user interface interactions with the device.
 - You can turn on Voice Assistant from any screen by pressing the Home key quickly three times (triple-press).
- **Voice Assistant help:** Tap for help on using Voice Assistant.
- **Dark screen:** Keep the screen turned off at all times for privacy.
- **Rapid key input:** Release your finger to enter selection instead of double tapping.
- **Speak passwords:** Read the characters aloud as you enter your passwords.
- **Font size:** Set the font size.
- **Magnification gestures:** Use exaggerated gestures such as triple-tapping, double pinching, and dragging two fingers across the screen.

- **Magnifier window:** Magnify content shown on the screen.
- **Grayscale:** Change all colors to gray.
- **Negative colors:** Reverse the display of onscreen colors from White text on a Black background to Black text on a White background.
- **Color adjustment:** Adjust the color of the screen if you are color blind or have difficulty reading the display because of the screen color. Tap **Color adjustment** for options.
- **Accessibility shortcut:** Quickly enable accessibility features in two quick steps. Tap **ON/OFF** to turn the feature on.
- **Text-to-speech options:** Set your preferred TTS engine and options.

Hearing

- **Turn off all sounds:** For privacy, turn off all notifications and audio.
- **Samsung subtitles (CC):** Use Samsung subtitles with multimedia files when available. Tap Samsung subtitles (CC) for options.
- **Google subtitles (CC):** Use Google subtitles with multimedia files when available. Tap Google subtitles (CC) for options.
- **Left/right sound balance:** Use the slider to set the Left and Right balance when using a stereo device.
- **Mono audio:** Switch audio from stereo to mono for use with one earphone.

Dexterity and Interaction

- **Universal switch:** Control your device with your customized switches.
- **Assistant menu:** Improve the device accessibility for users with reduced dexterity.
- **Tap and hold delay:** Select a time interval for this action.
- **Interaction control:** Block areas of the screen from touch interaction. Disable Auto rotate screen and hard key functions. Only show application notifications in the Notification panel and the Status bar.

More Settings

- **Direction lock:** Unlock the screen by swiping in a series of four to eight directions.
- **Direct access:** Open your accessibility settings by pressing the Home Key three times in quick succession.
- **Notification reminder:** Beep at set intervals to remind you of any unread notifications.
- **Single tap mode:** Tap to stop/snooze alarms and calendar events.
- **Manage accessibility:** Export your accessibility settings and share them with another device.

Services



Additional accessibility apps may be downloaded from the Google Play store. Certain accessibility services you install may be configured here.

Accounts



Set up and manage accounts, including your Google Account, Samsung account, email, and social networking accounts.

Depending on the account, you can choose to synchronize your calendar, contacts, and other types of content.

Add an Account

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accounts** > **Add account**.
3. Tap one of the account types.
4. Follow the prompts to enter your credentials and set up the account.

Synchronize Accounts



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accounts** > **[Account type]**.
3. Tap an account to view the sync settings for that account.
4. Tap individual data items to sync.
5. Tap **MORE** > **Sync all** or **Sync now** to synchronize the account.

Note: Sync options and the location of the sync command differ depending on the account type.



Account Settings

Each account has its own set of settings. In addition, you can configure common settings for all accounts of the same type.

Note: Account settings and available features vary between account types and service providers. Contact your service provider for more information on your account's settings.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accounts** > **[Account type]**.
 - Tap an account to configure that account's sync settings.
 - Tap other available options for the account.

Delete an Account



1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accounts** > **[Account type]**.
3. Tap the account and then tap **MORE** > **Remove account**.

Backup and Reset

Back up your data to Google servers. You can also reset your device to its factory defaults.



Backup and Restore Samsung Account

Enable backup of your information to Samsung servers.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Backup and reset** for options:
 - **Back up my data:** Enable back up of application data, Wi-Fi passwords, and other settings to Google servers.
 - **Restore:** Enable automatic restoration of settings from Samsung servers. When enabled, backed-up settings are restored when you reinstall an application.

Backup and Restore



Enable backup of your information to Google servers.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Backup and reset** for options:
 - **Backup account:** Select a Google Account to be used as your backup account.
 - **Back up my data:** Enable back up of application data, Wi-Fi passwords, and other settings to Google servers.
 - **Automatic restore:** Enable automatic restoration of settings from Google servers. When enabled, backed-up settings are restored when you reinstall an application.

Factory Data Reset

Return your device to its factory defaults.



Warning: This action permanently erases ALL data from the device, including Google or other account settings, system and application data and settings, downloaded applications, as well as your music, photos, videos, and other files.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Backup and reset** > **Factory data reset**.
3. Tap **RESET DEVICE** and follow the prompts to perform the reset.



Language and Input Settings

Configure your device's language and input settings.

Set Your Default Language

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input** > **Language**.
3. Select a language from the list.



Select Your Default Keyboard or Input Method

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input** > **Default keyboard**.
3. Select a keyboard.

Note: Additional keyboards can be downloaded from the [Google Play store](#).

Samsung Keyboard Settings



Configure options for using the Samsung keyboard.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input**.
3. Tap **Samsung keyboard** for options:
 - **Input languages:** Choose which languages are available on the keyboard. To switch between languages, slide the space bar sideways.
 - **Smart typing:** Allow Predictive text to suggest words matching your text entries, and, optionally, complete common words automatically. Predictive text can learn your personal writing style from your contacts, messages, Gmail, and social networking sites—improving its accuracy of predicting your text entries. Additional settings provide assistance with capitalization, punctuation, and much more.
 - **Key-tap feedback:** Adjust the sound and character preview when you tap a key.
 - **Customization:** Create shortcuts for your frequently used phrases and adjust keyboard size.
 - **Other settings:** Adjust the keyboard size and reset settings to their factory defaults.

Google Voice Typing Settings


Speak rather than type your text entries using Google Voice Typing.




Note: Some of these settings do not appear until you are logged in to a Google Account and use Google Search.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input**.
3. Tap **Google voice typing** for options:
 - **Language:** Select languages for Google voice typing.
 - **“Ok Google” detection:** Tap to launch a Google search whenever you say “Ok Google”.
 - **Hands-free:** Allow requests with the device locked.
 - **Speech output:** Select options for spoken feedback.
 - **Offline speech recognition:** Download and install speech recognition engines, allowing you to use voice input while not connected to the network.
 - **Block offensive words:** Hide words many people find offensive are in results of Google voice searches. Offensive words are replaced in results with a placeholder (####).
 - **Bluetooth headset:** Use audio input from a Bluetooth headset, if one is connected.

Voice Input




Use Google voice recognition to perform Google searches using spoken commands.

To perform a voice search, tap  in the Google search bar or widget. Or say “Ok Google” to launch a Google search (if the hotword detection option is enabled).

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input** > **Voice input** for options:
 - Tap **Enhanced Google services** for full voice interaction or **Basic Google recognition** for simple voice recognition.
 - Tap  **Settings** next to the selected recognition service to configure its options.



Text-To-Speech Options

Configure your Text-To-Speech (TTS) options. TTS is used for various accessibility features, such as Voice Assistant. For more information, see [Accessibility](#).

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input** > **Text-to-speech options** for options:
 - Choose either the Samsung or Google text-to-speech engine. Tap  **Settings** next to each TTS engine for options.
 - **Speech rate:** Set the speed at which the text is spoken.
 - **Default language status:** Display the default language in use.



Mouse/Trackpad Settings

Configure settings for using an optional mouse or trackpad (not included).

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Language and input** > **Pointer speed**.
3. Drag the slider to the right to go faster or to the left to go slower.
4. Tap **OK** to save your setting.

Battery

View how battery power is used for device activities.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Battery** for options:
 - **Power saving mode:** Tap **ON/OFF** to turn the feature on, and customize options.
 - **Ultra power saving mode:** Tap **ON/OFF** to turn the feature on.
 - **Display battery percentage:** Display the battery charge percentage next to the battery icon on the Status bar.

Battery Chart

The battery level displays as a percentage. The amount of time the battery has been used also displays.

- ▶ Tap **REFRESH** to update the listing.

Apps and System Usage

Battery usage displays in percentages per application and system process.

1. Tap **Screen, Android System, Android OS**, or an app to view how they are affecting battery use.
2. Tap **REFRESH** to update the listing.



Note: Other applications may be running that affect battery use.

Storage

View the device memory and usage.

Device Memory

View and manage the memory used by the device.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Storage**.
 - The Device memory displays Total space, which is the total space/free space in your phone's memory.
 - The amounts of memory used are further divided into:
 - **Available space**: The amount of storage space currently available.
 - **System memory**: The minimum amount of storage space required to run the system.
 - **Used space**: The amount of storage space currently being used.
 - **Cached data**: The amount of data currently cached.
 - **Miscellaneous files**: The amount of memory used to store miscellaneous files.

To increase available memory:

1. Tap **Cached data** to clear cached data for all apps. Tap **DELETE** to confirm.
2. Tap **Miscellaneous files**, select unnecessary files individually, or tap **SELECT ALL**, and then tap **DELETE**.

Memory Card (SD Card)

Once an optional memory card (not included) has been installed in your device, the card memory displays as Total space and Available space.

Install a Memory Card

You can use an optional microSD or microSDHC card (not included) to add additional memory space to your device.





Caution: Exercise care when using the metallic removal tool to eject the Memory card tray.

1. Insert the removal tool into the hole on the Memory card tray, and push until the tray pops out.
2. Place the Memory card on the tray, and slide the tray back into the slot.



Mount a Memory Card

When you install an optional memory card, it is automatically mounted (connected to the device) and prepared for use. However, should you unmount the card without removing it from the device, you have to mount it before it can be accessed.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Storage** > **Mount SD card**.



Remove a Memory Card

Warning: To prevent damage to information stored on the memory card, unmount the card before removing it from the device.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Storage** > **Unmount SD card**.
3. Insert the removal tool into the hole on the Memory card tray, and push until the tray pops out.
4. Remove the Memory card from the tray, and slide the tray back into the slot.

Format a Memory Card



Warning: When formatting an SD card, you should back up your music and photo files that are stored on the card because formatting the SD card deletes all the stored data.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Storage** > **Format SD card** and follow the prompts.

Accessories

Configure options when using an optional book cover (not included).



Flip the cover open to unlock the screen when secure lock is turned off.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **Accessories** > **Automatic unlock** to enable this feature.

Date and Time

By default, your device receives date and time information from the wireless network.

When you are outside network coverage, you may want to set date and time information manually using the date and time settings.

1. From a Home screen, tap  **Apps** >  **Settings**.



2. Tap **Date and time**.

The following options are available:

- **Automatic date and time:** When enabled, the device takes date and time updates from the wireless network.
- **Set date:** Enter the current date (only available when Automatic date and time is disabled).
- **Set time:** Enter the current time (only available when the Automatic setting is disabled).
- **Select time zone:** Choose your local time zone (only available when the Automatic setting is disabled).
- **Use 24-hour format:** Set the format for time displays.



User Manual

View tips and guidelines for using your device.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **User manual**.
3. For information about your device, tap **Basics**, **Applications**, **Settings**, or **Appendix**.



About Device

View information about your device, including status, legal information, hardware and software versions, and more.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **About device**, and then tap items for more details:
 - **Software update**: Check for and install available software updates.
 - **Status**: View the status of the battery, network, and other information about your device.
 - **Legal information**: View legal notices and other legal information.
 - **Device name**: View and change your device's name.
 - Additional device information includes the Model number, Android version, Build number, and more.

Software Updates

Use Software update to update your device's software.

1. From a Home screen, tap  **Apps** >  **Settings**.
2. Tap **About device** > **Software update** for the following options:
 - **Update now**: Tap and follow the prompts to check for available software updates to download and install.
 - **Auto update**: Alerts you whenever there is a new software update available.